

SHARP®

Version 1.0
Produced in Dec. 1997

Sharp Programmable Controller


Model name


I/O link master module ***JW-23LMH***


User's Manual

Safety Precautions

Read this user's manual and attached documents carefully before installation, operation, maintenance and checking in order to use the machine correctly. Understand all of the machine knowledge, safety information, and cautions before starting to use. In this user's manual, safety precautions are ranked into "Danger" and "Caution" as follows.



 **Danger** : Wrong handling may possibly lead to death or heavy injury.

 **Caution** : Wrong handling may possibly lead to medium or light injury.

Even in the case of  **Caution** , a serious result may be experienced depending on the circumstances. Anyway, important points are mentioned. Be sure to observe them strictly.

The picture signs of prohibit and compel are explained below.

 : It means don'ts. For example, prohibition of disassembly is indicated as ().

 : It means a must. For example, obligation of grounding is indicated as ().

1) Installation

Caution

- Use in the environments specified in the catalog and user's manual.
Electric shock, fire or malfunction may be caused when used in the environments of high temperature, high humidity, dusty or corrosive atmosphere, vibration or impact.
- Install according to the instruction manual and user's manual.
Wrong installation may cause drop, trouble or malfunction.
- Never admit wire chips or foreign matter.
Or fire, trouble or malfunction may be caused.

2) Wiring

Compel

- Be sure to ground.
Unless grounded, electric shock or malfunction may be caused.

Caution

- Wiring should be done by qualified electrician.
Wrong wiring may lead to fire, trouble or electric shock.

3) Use

Danger

- To avoid electrical shock, do not touch terminals when power is ON.
- Assemble the emergency stop circuit and interlock circuit outside of the programmable controller. Otherwise the machine breakdown or accident may be caused by the trouble of the programmable controller.

Caution

- Manipulation for program change, forced output, RUN or STOP during operation should be done with particular care by confirming safety. Misoperation may lead to machine trouble or accident.

4) Maintenance

Prohibit

- Don't disassemble or modify.
Or fire, trouble or malfunction may be caused.

Caution

- Turn OFF the power source before detaching or attaching the module.
Or electric shock, malfunction or trouble may be caused.

Chapter 1. Outline

Chapter 2. Safety Precautions for Use

Chapter 3. System Configuration

Chapter 4. Name and Function of Each Part

Chapter 5. Installation Method

Chapter 6. Wiring Method

Chapter 7. Module Operation

Chapter 8. Program Examples

Chapter 9. Error and Treatment

Chapter 10. Specifications

Appendix 1. Slave Module

Appendix 2. Check Flow

Appendix 3. Address Allocation Table of an I/O Link Slave Module

Table of Contents

Chapter 1 Outline	1
Chapter 2 Special Precautions for Use	2
Chapter 3 System Configuration	4
Chapter 4 Name and Function of Each Part	6
Chapter 5 Installation Method	7
Chapter 6 Wiring Method	11
[1] Wiring to terminal block	11
[2] Wiring with slave module	12
Chapter 7 Module Operation	14
[1] Timing of data exchange with PC	14
[2] Data flow between a master module and slave module	18
[3] Required transfer time	19
[4] Flag area	20
[5] I/O link area	21
Chapter 8 Program Examples	22
[1] System configuration	22
[2] Switch setting of a master/slave module	22
[3] Data memory allocation	23
[4] Program	24
Chapter 9 Error and Treatment	25
[1] Indication panel	25
[2] Flag area	26
[3] Status area	27
[4] PC system memory	31
Chapter 10 Specifications	32
Appendix 1. Slave Module	33
Appendix 1-1 ZW-82N/ZW-82S	33
[1] Name and function of each part	33
[2] Setting switch	34
[3] Installation method	36
[4] Wiring method	37
[5] Error and treatment	40
[6] Specifications	41
Appendix 1-2 ZW-161N/162N/161S/162S/164S/162M	44
[1] Name and function of each part	44
[2] Setting switch	45
[3] Installation method	47
[4] Wiring Method	50
[5] Error and treatment	52
[6] Specifications	53

Appendix 1-3 ZW-164NH/162SH/162MH	60
[1] Name and function of each part.....	60
[2] Setting switch	62
[3] Installation method	63
[4] Wiring method	66
[5] Error and treatment	68
[6] Specifications	69
Appendix 1-4 ZW-324NH/322SH/322MH	74
[1] Name and function of each part.....	74
[2] Wiring method	76
[3] Specifications	78
Appendix 1-5 ZW-84NC/162MC	83
[1] Name and function of each part.....	83
[2] Setting switch	85
[3] Installation method	86
[4] Wiring method	88
[5] Error and treatment	92
[6] Specifications	93
Appendix 2. Check Flow	97
Appendix 3. Address Allocation Table of an I/O Link Slave Module	98

Chapter 1 Outline

I/O link master module: JW-23LMH (hereafter called "master module") is I/O link master module for programmable controller JW20H/JW30H (hereafter called "PC").

The master module is connected to a PC basic rack panel and linked by a single twisted pair shielded cable to each of the I/O link slave module installed in various locations.

■ Features

1. High data transfer speed

The JW-23LMH transfer speed is 345.6 k-bit/sec., which is twice the conventional JW-23LM model. This allows high speed communications with the ZW-324NH/322SH/322MH I/O link slave modules. By setting the switches, the JW-23LMH can also be connected to the following conventional I/O link slave modules: ZW-82N/82S, ZW-161N/162N/161S/162S/164S/162M. In this case, the transfer speed will be 172.8 k-bit/sec.


2. Up to 32 slave module can be connected to a master module.

Up to 4 master module can be connected to a PC basic rack panel (excluding remote I/O slave station), and up to 32 slave module can be connected to 1 master module. (However, number of I/O link points is maximum 504 points.)

3. Each slave module can select between output hold and reset when a communication error occurs.

4. Module addresses of malfunctioning slave module are displayed.

Should a problem arise with a slave module, its address is displayed by the master module. This makes it easy to identify malfunctioning slave station.



This display shows that station No. 12 is malfunctioning.

5. Multiple errors can be monitored.

It is possible to monitor stations generating multiple errors, making it easy to recover readily.

Chapter 2 Special Precautions for Use

Observe the following precautions when using the master module.

1. Installation

Avoid installation in places such as these.

- Places that receive direct sunlight
- Panels in which high-voltage equipment is installed
- Places with flammable gases

2. Connecting

- Before connecting, you must set the "I/O link byte number setting switches" on the side of the master module.
- Connect the master module to the PC basic rack panel by plugging it into the I/O slot. Connections cannot be made to expansion rack panel and remote I/O slave station.
- Make connections only after cutting the power to PC. No more than 4 sets can be connected. If more than 4 sets are connected, the PC will not function.
- Do not install directly above equipment that generates much heat, such as heaters, transformers, or large-capacity resistance. Keep as far away as possible from high-voltage lines and power lines.
- The connecting screws should be zinc-plated M3 screws. Tighten firmly when connecting.

3. Wiring


- Before wiring, check all connections and switch settings.
- Avoid laying communication cable in parallel proximity to power lines or other high-voltage or high-current lines.
- Wiring that makes connecting and disconnecting easy will facilitate subsequent maintenance work.
- Do not remove the caution label affixed to the top of the unit. This will prevent cable waste and other foreign matter generated during wiring from entering the ventilation hole, which is provided to keep the interior temperature from rising. Remove the caution label only after all wiring has been completed.
- For wiring, use Sharp-recommended twisted pair shielded cable.

Recommended twisted pair shielded cable

Wiring system	Cable model	Manufacturer
2-wire system	S-IREV-SW2 * 0.5	Hitachi Cable Ltd.
	S-IREV-SB2 * 0.5	
	RG-22B/U	Fujikura Ltd.

- Use Sharp-recommended crimp-style terminals for wiring to the terminal block.

Terminal block dimensions (mm)



- Recommended crimp-style terminals (made by Japan Solderless Terminal Mfg. Co., Ltd.)

Crimp-style terminal	Dimensions	Model name
	$B < 8.1$ $d_2 > 4$	1.25 - YS4A
		V1.25 - YS4A
		2 - YS4A
		V2 - YS4A

4. Switch setting and operation

- Set switches only after disconnecting power to PC. Setting switches while power is ON could cause a malfunction. Do not use excessive force to operate switches.
- In case of JW20H, after setting switches and supplying power to the PC, register I/O by using support tool (JW-13PG, etc.). Unless I/O is registered, the PC and master module do not operate.
- If there is trouble or error in the master module (overheat, malodor, smoke, etc.), stop using and immediately report to your dealer or our service company.

5. Static electricity

- Under very dry conditions the human body generates excessive static electricity, which could adversely affect master and slave module. Begin working on module only after touching grounded metal or the like to discharge static electricity from your person.


6. Cleaning

- Use a soft, dry cloth. The use of volatile substances (such as alcohol, thinner, or freon), a damp cloth, or the like could cause deformation or discoloration.

7. Assignment of relay numbers

- JW20H/30H connected to a JW-23LMH master module are assigned 16 points as I/O relay numbers on the JW-23LMH. These 16 points constitute a dummy area that is not used on the JW-23LMH. (See page 23.)
- The JW20H and JW30H allocation of I/O link area and flag area is not the same. (See page 9.)

Chapter 3 System Configuration



3

Master module

Model	Remarks
JW-23LMH	<ul style="list-style-type: none"> 4 sets of JW-23LMH can be installed on the basic rack panel I/O slot of the JW20H/ JW30H. 32 sets of slave module can be connected per master module. Set in mode switch for transfer rate (345.6 kbits/s, 172.8 kbits/s.) Total cable length is 1 km at maximum.

I/O link slave module

Model name		No. of points	Specifications	
Input	ZW-82N	8 points	12/24 VDC	(Transfer rate) 172.8 kbits/s
	ZW-161N	16 points	100 to 120 VAC	
	ZW-162N	16 points	12/24 VDC	
	ZW-164NH	16 points	24 VDC	345.6 kbits/s, 172.8 kbits/s※
	ZW-324NH	32 points	24 VDC	
ZW-84NC	8 points	24 VDC		
Output	ZW-82S	8 points	12/24 VDC, 0.3 A, transistor output	172.8 kbits/s
	ZW-161S	16 points	100 to 120 VAC, 0.5 A, triac output	
	ZW-162S	16 points	12/24 VDC, 0.3 A, transistor output	
	ZW-164S	16 points	264 VAC/30 VDC, 2 A, relay output (separated common)	345.6 kbits/s, 172.8 kbits/s※
	ZW-162SH	16 points	24 VDC	
	ZW-322SH	32 points	24 VDC, 0.3A, transistor output	
I/O	ZW-162M	16 points	12/24 VDC, 0.3 A; transistor output 8 points, 12/24 VDC input 8 points	172.8 kbits/s
	ZW-162MH	16 points	24 VDC	345.6 kbits/s, 172.8 kbits/s※
	ZW-162MC	8 points	24 VDC	
	ZW-322MH	32 points	24 VDC, 0.3 A, transistor output 16 points 24 VDC, input 16 points	

※ The data transfer speed changes automatically according to the data transfer speed of the JW-23LMH master station.

■ LCD terminal

Model name	Remarks
Z-SM10	<ul style="list-style-type: none"> • Dot matrix, super twist LCD panel • Number of dots: 240 × 128 dots • Available indication area: 134 × 76 mm



■ Manifold solenoid valve

Series	Corresponding module	Manufacturer
VQ 0000/1000/2000	EX120-SSH1	SMC Co., Ltd.
SY 3000/5000	EX121-SSH1	
SX 3000/5000	ES122-SSH1	
	EX130-SSH1	
VZS 2000/3000	IN313-SH1	
VFS 2000/3000/4000/5000		
VFR 2000/3000/4000		
M4TB1/2	OPP-14	CKD Co., Ltd.
M4LB2/3		
110, 180, 240	FIT-SP	Koganei Seisakusho Co., Ltd.
SR530/540/550/551/561	SRS-2416	Taiyo Tekko Co., Ltd.
Valve terminal	FB-20	Fest Co., Ltd.

■ Signal transformer

Model name	Specifications	Manufacturer
28S series	Sensor input transformer	M-System Giken Co., Ltd.
	Distributor (transformer for 2-wire transmitter)	
	Characteristic transformer	
	Isolator	


Chapter 4 Name and Function of Each Part




Lamp name	Operation contents
CM	Turn ON a light when communicating
SY	Turn ON a light when setting ON for 7 (SY) of I/O link bytes setting switch SW2.
HL	Turn ON a light when internal HALT relay is "ON."
CH	Turn ON a light when "mode switch" is set to "3 or 6," it is valid, and when internal relay (check relay) is "ON."
MS	Turn ON a light when connected check for master module, slave module is impossible.
ER	Turn ON a light when switch setting of master module is error or communication line is error.
FT	Turn ON a light when hardware of master module is error.
ME	Turn ON a light when master module is error.
SE	Turn ON a light when slave module is error.
40 to 1	Display the error code at error or station number of error slave module.

Chapter 5 Installation Method

Following are the procedures to be followed for installation and setting switches.



Turned OFF all switches at delivery




① Set the "I/O link byte setting switch SW2," located on the module's side.

• **Setting the I/O link bytes switch**
(switches: 1 to 6)

Set in octal the total number of bytes occupied by slave module.

Example: When 4 sets of the 32 points type are used.


Setting value = 4 bytes × 4 = 16 bytes_(D) = 20₍₈₎



• **Communication cycle (switch: 7)**

Select whether or not communication with PC is to be synchronized with PC operations (see page 15).

Synchronous: ON Asynchronous: OFF



Note


- The test mode (switch 8) should always be "OFF."
- Connecting a number of slave modules that is larger than the number of I/O link bytes could cause a malfunction owing to a data conflict.
- If the number of I/O link bytes set is larger than the total number of bytes occupied by the slave module, communication errors (mode 1) will be generated.

② Push in the master module by hanging the retention rib on the bottom rear part of the master module on the inserting hole of fixing rib on the basic rack panel.

- If the master module is pushed in without hanging the module retention rib in the insertion slot, it cannot be correctly installed on the basic rack panel.
If the installed module is tilted after pushing it in, repeat the procedure from the beginning.

Continued next page

Continued from previous page




③ Use a phillips screwdriver to tighten the module retention screw on the upper part of the module.



- If the screw is not properly tightened, perform installation over from the beginning.

④ Use a slot screwdriver to remove the "switch cover" from the front panel.

- To remove the cover, insert the slot screwdriver into the gap between the switch cover top and cabinet, and pull it toward yourself while pushing down.



⑤ Set the "mode switch" to the desired operation mode and transfer rate.



Set to "1" at delivery

		Mode switch setting value					
		1	2	3	4	5	6
At normal	• When power to the master module turns "ON," the master module initially checks its connected stations one time.	○	○	○	○	○	○
	• The master module continues to check its connected stations once per 100 communications with all save module.	○	○	-	○	○	-
	• When the CHECK relay is "ON," the master module checks its connected stations.	-	-	○	-	-	○
Operation contents	• The master module repeats connected station check until communication becomes normal.	○	-	-	○	-	-
	• The master module checks its connected stations once per 100 communications with all slave module, and check no response station's recovery	-	○	-	-	○	-
	• When the CHECK relay is ON, the master module checks its connected stations, and check no response station's recovery.	-	-	○	-	-	○
At communication error	• The master module executes communication regarding no response slave module as disconnected station.	-	○	○	-	○	○
	• No response station number is output to display panel and status section.	○	-	-	○	-	-
	• Only PC 1 cycle of no response station number is output to status section.	-	○	○	-	○	○
Transfer rate: (kbits/s)		172.8		345.6			


Note

- Set the mode number switch to "1" through "6." If the switch is set to "0" or "7" through "9," errors will arise and the module will not function.
- When two or more stations slave module are functioning improperly, the status port and display panel will show the address of the minimum number.

Continued next page

5

Continued from previous page



⑥ Use the "module number switch" on the front to set the module address.

Setting the module address will assign the I/O link area and the flag area.

- If a PC is the JW20H...

When 4 master modules are installed:

Switch setting	I/O link area	Flag area
0	∩0100 to ∩0117 (128 points)	∩1570 to ∩1571
1	∩0120 to ∩0137 (128 points)	∩1572 to ∩1573
2	∩0140 to ∩0157 (128 points)	∩1574 to ∩1575
3	∩0160 to ∩0177 (128 points)	∩1576 to ∩1577

When 3 master modules are installed:

Switch setting	I/O link area	Flag area
0	∩0100 to ∩0117 (128 points)	∩1570 to ∩1571
1	∩0120 to ∩0137 (128 points)	∩1572 to ∩1573
2	∩0140 to ∩0157 (256 points) ∩0160 to ∩0177	∩1574 to ∩1575

When 2 master modules are installed:

Switch setting	I/O link area	Flag area
0	∩0100 to ∩0117 (128 points)	∩1570 to ∩1571
1	∩0120 to ∩0137 ∩0140 to ∩0157 (384 points) ∩0160 to ∩0177	∩1572 to ∩1573

When 1 master module is installed:

Switch setting	I/O link area	Flag area
0	∩0100 to ∩0117 ∩0120 to ∩0137 (512 points) ∩0140 to ∩0157 ∩0160 to ∩0177	∩1570 to ∩1571

- When a PC is the JW30H:


Switch setting	I/O link area	Flag area
0	∩2000 to ∩2077 (512 points)	∩1570 to ∩1571
1	∩2100 to ∩2177 (512 points)	∩1572 to ∩1573
2	∩2200 to ∩2277 (512 points)	∩1574 to ∩1575
3	∩2300 to ∩2377 (512 points)	∩1576 to ∩1577

Note

- Set the module number switch to "0" to "3." If the switch is set to "4" to "9," errors will arise and the module will not function.
- Make sure the switch setting does not duplicate that of another master module. If there is a duplicate, neither the PC nor the master module will function. PC system memory #160 will store the error code "73_(H)" and turn on the master module's ER lamp.
- The first byte of the I/O link area is the status area.

Continued next page

Continued from previous page




⑦ Set the "termination resistance switch" on the front.

- When setting termination resistance switches, those for stations "ON" the ends of I/O link lines should be ON, and all other stations should be "OFF."

- It is set to "ON" at delivery.


- Setting example:

In the diagram below, slave station 3 and the master station shall be set to "ON," while the other stations shall be set to "OFF."




⑧ Replace the switch cover

⑨ Procedure completed



Chapter 6 Wiring Method

[1] Wiring to terminal block



※ SHIELD terminal and FG terminal are shorted using a shorting tab.



Note

- ★ Use our recommended twisted pair shield cable for wiring to the terminals L₁, L₂, and SHIELD. When wiring the shield line to the terminal block, it is convenient to relay the twisted cable with 0.5 mm² at the outside of the shield cable.
- ★ Cables from the shield cable should be kept as short as possible (below 30 mm).
- ★ Do not connect signal cables to the FG (frame ground) terminal.
- ★ Use 1.25 mm² twisted cables to connect the FG (frame ground) terminal to a class 3 ground via the basic rack panel.
- ★ Use the crimp-style terminals for wiring to terminal block.
- ★ After wiring, check again the wiring and the retention condition.

[2] Wiring with slave module

Wire with the 2-wire system


[Example]




6

Note


- ★ Connect the shield line of the cable with SHIELD terminal.
- ★ Be sure to short circuit between the SHIELD terminal and the FG terminal of the slave module (ZW-82N/82S, ZW-161N/162N/161S/162S/164S/162M) outside the module.
- ★ Be sure to execute class-3 grounding for the FG terminal of the master module and slave station via the basic rack panel. Avoid co-grounding with other modules. If not grounded, modules easily pick up electric noise, which causes a malfunction.
- ★ Do not execute multiple-wiring from one source point for communication cable.



- ★ Keep the communication cable as far away as possible from the high voltage and power lines, so as not to close in parallel.
- ★ Use our recommended cable for communication cable and keep its total length within 1 km.
- ★ Not necessary to set the master module and the slave module in order, one by one, nor setting the master module as end station. The following example is available.



- ★ Do not wire load driving cables and power supply in the same duct of communication cable. (For the cable supplying power to a slave module exclusively and not for load driving, wiring in the same duct is available.)




- ★ In case of JW20H, after completion of installation and wiring, use the support tools (such as the JW-13PG) to perform "I/O registration." Without "I/O registration" the PC will not operate. As for operating procedure of I/O registration, see the instruction manual attached to the support tool.


Chapter 7 Module Operation

[1] Timing of data exchange with PC

- Data exchange between the master module and PC is performed with the PC's "optional processing."




- Internal structure of master module and PC



Name of section	Functions
Common memory	<ul style="list-style-type: none"> This is the memory for storing output data for slave module and input data from input module. Also used to store control commands.
CPU2	<ul style="list-style-type: none"> This is CPU of the master module. The CPU2 exchanges data with the PC and controls SIO.
Processing memory	<ul style="list-style-type: none"> This is the internal processing memory of the master module.
SIO	<ul style="list-style-type: none"> This is control circuit for serial communication.
Common RAM access controller	<ul style="list-style-type: none"> This controls the common RAM.
Data memory	<ul style="list-style-type: none"> This is data memory for the PC.
CPU1	<ul style="list-style-type: none"> PC's CPU Data exchange with master module and user program processing.


• **When I/O link communication time is shorter than PC scan time**

(Communication cycle: Asynchronous/synchronous)




• **When I/O link communication time is longer than PC scan time**

(Communication cycle: Asynchronous)




(Communication cycle: Synchronous)




Note

- ★ When the mode switch is set to "1, 2, 4, 5", I/O link communication will be carried out 100 times, and connected station confirmation will be performed once, but at this time there will be no exchange of data.

• **Operation when checking connected station**




• **Operation at time of I/O link communication trouble**



Note

★ Communication check is effected by connected station check, which is repeated until normal operation resumes.


Mode switch: 2, 5



Note

- ★ When the master module detects incoming data trouble:
- ① It performs a slave module connected station check once.
 - ② If there is a problem, it performs a connected station recheck, outputs 1 scan of status information, and resumes I/O link communication.
 - ③ It regards the malfunctioning slave station as an unconnected station, and outputs that slave station's address for 1 scan once in 100 connected station rechecks.

Mode switch: 3, 6




Note

★ When the master module detects incoming data trouble:

- ① It outputs 1 scan of status information, and resumes I/O link communication.
- ② It regards the malfunctioning slave station as an unconnected station, and executes communication.
- ③ It performs a connected station recheck when the CHECK relay is "ON."


■ **When the CHECK relay is "ON"**

When the CHECK relay is "ON," the JW-23LMH checks connected stations.



[2] Data flow between a master module and slave module

(⇐) Input signal data, (⇒) Output signal data



Note

7

- ★ I/O processing of a slave module is executed after completing communication with its master station.
- ★ Time lag exists between optional processing of the PC and I/O processing of the slave module.

[3] Required transfer time

- This is the time required for a master module to communicate with all stations. The following calculation includes actual communication time and internal processing time of the master module.

$$T = T_A + (T_B + T_S) N \text{ (ms)}$$

Where,

- N : Total number of bytes occupied by the slave module input/output. (Unit: 1 byte)
T_A : Preprocessing time of the master module. (1.3 ms)
T_B : Time to process 1 byte in the master module. (0.117 ms).
T_S : Necessary time to communicate 1 byte with a slave module. (Unit: ms)

$$\left[\begin{array}{l} \text{Transfer rate 172.8 k bits/s} = 0.228 \text{ ms} \\ \text{Transfer rate 345.6 k bits/s} = 0.114 \text{ ms} \end{array} \right]$$

Note

- ★ All calculation should be executed in decimal.


[Example] Required transfer time at communicating with I/O link slave module ZW-322SH (32 points output module) × 10 sets

(Transfer rate 345.6 k bits/s)

$$T = 1.3 + (0.117 + 0.114) \times 40 = 10.54 \text{ ms}$$

[4] Flag area

2 bytes are used for the flag area, with "connected station check," "communication stop," and other items set using the upper byte, and "error read out information" being set using the lower byte.



↑
When module number switch is set to "0."

Relay	Name	Contents
CHECK	Connected station check relay	<ul style="list-style-type: none"> Relay which becomes effective when the mode changeover switch is set to "3." When this relay is "ON," the module repeatedly executes connected station check processing. (When executing connect station check processing, communication with slave modules is interrupted. The output status of slave module is determined by their switch settings.)
HALT	HALT relay	<ul style="list-style-type: none"> When this relay is "ON," communication with slave module is halted. (The output status of slave module is determined by their switch settings.)
Operation relay Read out relay	Hand shake flag	<ul style="list-style-type: none"> Read out flag for number of malfunctioning slave module (including unconnected stations) and address of malfunctioning slave station.
Error data	No. of errors, malfunctioning slave station check	<ul style="list-style-type: none"> Uses operation with handshake flag to show number of errors or address of malfunctioning slave station.

7

[5] I/O link area

Used as the storage area for master module and slave module data.

Example: When the I/O link byte number setting switch is set to 16 bytes_(D) (20 bytes₍₈₎)



- Two 16 points slave module, four 8 points slave module, and two 32 points slave module are used.
- There is 1 master module (when the module number switch is set to "0")

JW30H	JW20H	
⌘2000	⌘0100	Status
⌘2001	⌘0101	Slave module 01 ₍₈₎ (16 points) data
⌘2002	⌘0102	
⌘2003	⌘0103	Slave module 03 ₍₈₎ (16 points) data
⌘2004	⌘0104	
⌘2005	⌘0105	Slave module 05 ₍₈₎ (8 points) data
⌘2006	⌘0106	Slave module 06 ₍₈₎ (8 points) data
⌘2007	⌘0107	Slave module 07 ₍₈₎ (8 points) data
⌘2010	⌘0110	Slave module 10 ₍₈₎ (8 points) data
⌘2011	⌘0111	Slave module 11 ₍₈₎ (32 points) data
⌘2012	⌘0112	
⌘2013	⌘0113	
⌘2014	⌘0114	
⌘2015	⌘0115	Slave module 15 ₍₈₎ (32 points) data
⌘2016	⌘0116	
⌘2017	⌘0117	
⌘2020	⌘0120	
⌘2077	⌘0177	Not used

Diagram annotations: A vertical double-headed arrow on the right indicates a total size of 64 bytes. A horizontal line above the 'Status' row is labeled '1 byte'. A vertical double-headed arrow on the right, spanning from the 'Status' row down to the 'Not used' row, is labeled 'Number of I/O link bytes 20 bytes₍₈₎'.

Reference

Status is an area to indicate I/O link communication state.


Slave station data are communication area with each slave module.

- When slave module is input, slave station data is PC input data.
- When slave module is output, slave station data is PC output data.
- When slave module is input and output, the first half of slave station data is allocated to output, and the second half to input.

Chapter 8 Program Examples



[1] System configuration

- ① Master module 1 set
 Slave modules:
 One 32 points input module
 One 32 points output module
- ② Two 16 points DC input module (JW-212N) 2 sets
 Install operation switches and send a signal to slave module (output).
- ③ Two 16 points DC output module (JW-212S) 2 sets
 Display input signals from slave module (input).
- ④ One 16 points DC output module (JW-212S) 1 set
 Used for monitoring status of I/O link communication.



[2] Switch setting of a master/slave module

- ① Switch setting of a master module
 - Setting of the module No. switch: "0"
 - Setting of the mode switch: "5: transfer rate 345.6 k bits/s"
 - Setting of the number of I/O link byte setting switch:
 Number of I/O link bytes : 8 bytes_(e); 10 bytes_(e)
 Communication cycle : Synchronize
 - Setting of the termination resistance switch:



② Setting the switch of slave module



- Setting the address switch

Slave station No.	01 _(e)	05 _(e)
Setting switch	40 20 10 4 2 1 ON ↑	40 20 10 4 2 1 ON ↑

- Setting the termination resistance

Slave station No.	01 _(e)	05 _(e)
Termination resistance of mode switch	OFF	ON

[3] Data memory allocation




I/O link area

JW30H	JW20H		
32000	30100	D ₇ , D ₆ status information	Status section
32001	30101	Slave station 01 _(a)	
32002	30102		Slave module (input) (ZW-324NH × 1)
32003	30103		
32004	30104		
32005	30105	Slave station 05 _(a)	
32006	30106		
32007	30107		
32010	30110		
32011	30111	Not used	64 bytes
32077	30177		


[4] Program

(1) When a PC is a JW20H



- Transfers slave module (input) information for monitoring.
- Transfers switch input to the allocated slave module address of the slave module (output).
- Transfers status information when error occurs for purpose of monitoring.

(2) When a PC is a JW30H




- Transfers slave module (input) information for monitoring.
- Transfers switch input to the allocated slave module address of the slave module (output).
- Transfers status information when error occurs for purpose of monitoring.

8

Chapter 9 Error and Treatment

You can see the self-diagnosis results using the "indication panel," "flag area," "status area," and "PC system memory (#160)."

[1] Indication panel




LED display	Description	Action
CM	On when communicating	_____
SY	On when communication cycle setting is "synchronous"	_____
HL	On when internal HALT relay is "ON"	_____
CH	On when "mode switch" is set to "3," and when internal relay (CHECK) is "ON"	_____
ER	On when there is a master module switch setting problem	Check switches and reset.
	On when there is a communication line problem	Check communication cable. Change master or slave module.
FT	On when there is master module trouble	Change master module.
ME 2	On when there is master module line trouble	Change master module.
ME, SE 40 to 1	On when there is a master module switch setting problem	Reset number of occupied bytes to 1 to 77 ^(B) .
MS, SE 40 to 1	On when connected station check for slave station 01 is impossible (communication problem)	Check communication cable wiring. Make sure slave module power supply is "ON." Check master station I/O byte number setting switch.
	On when connected station check for slave station 77 is impossible (communication problem)	Check slave module address setting. Change slave module.
※ SE 40 to 1	On when there is I/O link communication trouble with slave station 01	Check communication cable wiring. Make sure slave module power supply is "ON."
	On when there is I/O link communication trouble with slave station 77	Make sure there are no duplicate slave module address settings. Change slave module.
All LEDs OFF	Off when "mode switch" is set to "3," CHECK relay is "ON," and connected station check is normal.	_____

※ You can check I/O link communication problems at the master module only by a data check from input slave module.


[2] Flag area

- Allows you to find the number of errors or the addresses of malfunctioning slave stations.




↑
When module number switch is set to "0."

- Operation example
When the master module's module number switch is set to "0":
(Flag area ⊠1570 to ⊠1571)



[3] Status area

- The lower 6 bits input malfunction information, and the upper 2 bits input the malfunction flag, into the PC.



① Error flag

Bit	Error contents	Related processing
D_6	<ul style="list-style-type: none"> When checking connected stations during power "ON" and I/O link communication, this bit turns "ON." When errors exist in received input signal data, this bit turns "ON." 	<ul style="list-style-type: none"> Outputs to an indicator lamp. Address of malfunctioning slave station is output to status.
D_7	<ul style="list-style-type: none"> When the master module is error, this bit turns "ON." When mis-setting of the master module switch occurs, this bit turns "ON." 	<ul style="list-style-type: none"> Outputs to an indicator lamp. Outputs error code to status.

② Malfunction information (when D_6 is "ON")

- Error informations of D_0 to D_5 varies depending on D_6 and D_7 . Error information of D_7 "ON" has priority.
- Address of malfunctioning slave module is output to " D_0 to D_5 ".
- Each bit of D_0 to D_5 expresses weight of octal figure. [$00_{(8)}$ to $77_{(8)}$]

D_5	D_4	D_3	D_2	D_1	D_0
×40	×20	×10	×4	×2	×1

- The error slave module number is the address set by the slave module address setting switch.
- When more than one error slave module exists, the master module outputs the smallest address number.
- LED status is as shown below when D_6 is "ON."

●: Lights

Contents	Error slave module No. D_0 to D_5	Indicator lamp					Priority
		CM	ER	FT	MS	1 to 40	
Communication error (Unable to check connected station)	$01_{(8)}$ to $77_{(8)}$ ※2	●	●		●	Shows address of malfunctioning slave station	5
Communication error (At I/O link) ※1	$01_{(8)}$ to $77_{(8)}$	●	●				6
Normal communication	$00_{(8)}$	●					7

※1: It is only data problems from input slave module that can be detected with a master module.

※2: When more than one error slave module exist, the master module indicates the smallest slave station address while flickering.

- (Check the following when you experience communication problems.)
- ① Is the communication cable broken?
 - ② Is the slave module address correct, and is the power "ON"?
 - ③ Is the master module's number of I/O bytes set correctly?
 - ④ Should the slave module be replaced?

③ Error information (When D₇ is "ON")

- Error codes (hexadecimal) are output to D₀ to D₅.

●: Lights, ○: Blinks

Error code (hexa- decimal)	Error contents	Indicator lamp			Status	Remedy	Priority
		CM	ER	FT			
0	Line check error		●		No output	※	3
1	ROM error			●	D ₀ : [ON]	Exchange master module	1
2	RAM error (1) (CPU inside RAM)			●	D ₁ : [ON]		
3	RAM error (2) (For data processing)			●	D ₀ , D ₁ : [ON]		
4	Memory error for data exchange with PC			●	D ₂ : [ON]		
5	Communication control timer			●	D ₀ , D ₂ : [ON]		
8	Switch mis-setting		●		D ₀ , D ₇ : [ON]	Reset switch	2
—	PC stops operation (program mode)	○			No output	—	4

※ Check for shorted signal cable, or change the slave or master module.

- When error flags D₆ and D₇ are both "ON" at the same time, the error information of D₇ has priority.

④ Relationship between operation mode and malfunction information (D₆, D₇)

- The operation mode settings will determine the “status area,” “master module,” and “slave module” operation displays at times of malfunctions, as shown below.

●: Lights, ◐: Blinks

Setting mode	Error contents	Master module										Slave module						
		Status			Indicator lamp							Indicator lamp		Output condition of output hold switch				
		D ₆	D ₇	D ₀ to D ₅	I/O link communication	CM	ER	FT	ME	SE	1 to 40	RUN	ERROR	OFF	ON			
1 or 4	Master module switch setting error		●	Error contents	Stop		●		●	●	All light	●	●	—	Reset Reset Hold			
	Slave module error or power "OFF"	●		Error slave station address No.	Check connected station	●	●			◐	Error code indication (blinks)			Reset				
	Communication error (Input module)	●				●	●			◐		●	●	Hold				
	Communication error (Output module)	●				●	●			◐		●	●					
2 or 5	Master module switch setting error		●	Error contents	Stop		●		●	●	All light	- Ditto -						
	Slave module error or power "OFF"	●		Error slave station address No.	Continue I/O link communication	●					—							
	Communication error (Input module)	●				●										—		
	Communication error (Output module)	●				●										—		
3 or 6	Master module switch setting error		●	Error contents	Stop		●		●	●	All light	- Ditto -						
	Slave module error or power "OFF"	●		Error slave station address No.	Continue I/O link communication	●					—							
	Communication error (Input module)	●				●										—		
	Communication error (Output module)					●										—		

When the mode is set to 2 or 5, the ER display lamp lights for two seconds and the SE display lamp and LEDs 1 to 40 will flash for 2 seconds if a processing error has occurred, the power is OFF, or a communication error has occurred.

Note

★ When the mode setting is "3 or 6," indicator lamps are as shown below during connected station checks by the CHECK relay.

Error contents	Master module										Slave module			
	Status			I/O link communication	Indicator lamp						Indicator lamp		Output condition of output hold switch	
	D ₆	D ₇	D ₀ to D ₅		COM	ER	FT	ME	SE	1 to 40	RUN	ERROR	OFF	ON
Master module switch setting error		●	Error contents	Stop		●		●	●		●	●		
Slave module error or power "OFF"	●		Error slave station address No.	Continue check connected station	●	●			①	Error code indication (blink)			Hold	
Communication error (Input module)	●				●	●			①		●	●	Reset	
Communication error (Output module)	●				●	●			①		●	●	Reset	

[4] PC system memory

- When the master module malfunctions, PC system memory #160 will store the error codes.

Error code	Contents
40 _(H)	Installed module error
44 _(H)	I/O data bus error
※ 53 _(H)	Hard error (option error)
60 _(H)	Table verification error
61 _(H)	Module number switch verification error
70 _(H)	Table registration error
73 _(H)	Module number switch setting error

- ※ If you are using a JW30H, when error code 53_(H) is stored in system memory address #160, the I/O link master module in which the error occurred can be identified according to its switch number on the basic rack panel by reading system memory #051. (See the JW30H's programming manual)
In case of JW20H, switch number of error I/O link master module can't check.

- Operating conditions of master/slave module become as follows in compliance with the PC conditions, run, stop, error and power OFF.

●: Lights, ◐: Blinks

PC operating condition	PC			Master module						Slave module				
	Indicator lamp		System memory #160	Indicator lamp						Indicator lamp		Output module output hold switch		
	RUN	FAULT		CM	ER	FT	ME	SE	1 to 40	RUN	ERROR	OFF	ON	
Normal operating	●			●							●		-	-
Stopping	◐			◐							●	●	Hold	Reset
I/O link master module error		●	Error code			●	●		●	●	●			
Power "OFF"										●	●			
At HALT relay "ON" (at PC operation)	●			●						●				


- When the HALT relay of the master module is "ON," the HOLD lamp of slave module light.

Chapter 10 Specifications

Item	Specifications
No. of I/O link station	Max. 32 stations
No. of I/O link point	Max. 504 points (63 bytes)
Number of I/O occupied points	I/O relay : 16 points (2 bytes) Flag area : 16 points (2 bytes) I/O link area : In case of JW20H, Max. 512 points (64 bytes), In case of JW30H, 512 points (64 bytes)
Synchronous with PC processing	Synchronous/asynchronous
Data transfer standard	EIA RS485 or equivalent
Transfer rate	345.6 k bits/sec., 172.8 k bits/sec. (Changeover by the mode switch)
Transfer format	Start-stop synchronous system
Coding method	NRZ (Non Return to Zero)
Frame check	Parity check and double-reverse check
Synchronous mode	Start-stop system
Transfer mode	Time sharing cyclic digital
Communication line	Party line Shielded twisted pair cable Cable total length: 1 km max.
Storage temperature	-20 to 70°C
Ambient operation temperature	0 to 55°C
Ambient humidity	35 to 90% RH (without dew condensation)
Vibration resistance	JIS-C-0911 or equivalent (2 hours for X, Y, and Z axes)
Shock resistance	JIS-C-0912 or equivalent (10G, 3 times for X, Y, and Z axes)
Power consumption (5 VDC)	120 mA
Operator indication	CM, SY, HL, CH, MS, ER, FT, ME, SE 40, 20, 10, 4, 2, 1 (abnormal slave station number)
Outer wire connection	6P terminal block (M 4.0 x 7 screws)
Weight	Approx. 220 g
Accessories	One instruction manual

[Outside dimensions]





(Unit: mm)



Appendix 1. Slave Module

Appendix 1-1 ZW-82N/ZW-82S

[1] Name and function of each part



A1


[2] Setting switch

Be sure to turn OFF the power to the PC before setting switches. Setting switches while power is ON could cause a malfunction.


(1) Address setting switch (ST No.)

Set slave station number (ST No.).

- Set from "01" in octal notation.
- Set which byte of the "I/O link area" in the master module is used.



Example: When using two 16 points slave module and one 8 points slave module:



Note

★ Duplicate setting of slave station addresses will result in a malfunction.


Duplicate setting	Operation
If two input modules have the same address	Unspecified input data
If an input module and an output module have the same address	Unspecified data and output module condition
If two output modules have the same address	Output of same data

★ The slave station address of the LCD terminal Z-SM10 shall be set in decimal notation.

A1

(2) Mode setting switch


Sets termination resistance, function, and other items.



① Termination resistance

- When setting termination resistance switches, those for stations on the ends of I/O link lines should be "ON," and all other stations should be "OFF."
- The delivery setting is "ON."
- Setting example:

In the diagram below, slave station 03_(B) and the master station are set to "ON," while the other stations are set to "OFF."



② Function setting switch

- Sets "OFF : I/O link" as communication functions.
- The delivery setting is "OFF."
- Module will not operate, if turned "ON."

③ Output hold switch (on output module only)

- When the I/O link communication is error, set the operation at the slave module side. If there is no communication from the master module for more than 1 second, it is judged that the communication is suspended.

The communication is also suspended when the master module HALT relay is "ON."

Setting value	Function	Description
ON	Reset	All outputs are "OFF" when communication is suspended.
OFF	Hold	Output before suspension is held when communication is suspended. ※

※When the CPU is error (when the watchdog timer is actuated), all outputs are "OFF."

④ Output prohibit switch (on output module only)

- This is the communication test switch of output module.

Setting value	Function	Description
ON	Permit	Lamp of output module and output element are "ON/OFF" depending on the output signal of PC.
OFF	Hold	Output elements are all "OFF" regardless of PC output signal.


A1

[3] Installation method

(1) Installation



Avoid keeping slave module in the following condition.

- Direct sunlight.
- Ambient temperatures below 0°C and over 55°C.
- No condensation due to rapid temperature variation.
- Relative humidity which exceeds 35 to 90%.
- Corrosive and flammable gases.
- Dusts, iron, and salty conditions.
- Vibration and shock producing and transferring positions.
- Slave module should be installed with its top facing up.



- As module are not dustproof or waterproof, install them in sealed cabinets if at all possible.
- Avoid installation just above high calorie heat generating devices (heaters, transformers, high capacity resistance etc.). Also avoid to install other equipment close to slave module.
- Avoid installation in a box in which high voltage device is installed.
- As much as possible keep away from high voltage cables and power cables.
- install on a good conductivity metal plated panel instead of painted one for easy grounding and better noise tolerance.
- Use zinc plated retention screws of M3 for installing slave module.

(2) Installation dimensions




- Secure 50 mm or more space above and below the module for heat radiation. Keep away for 30 mm or more between modules for wiring.
- Use 2 M3 x 10 screws for retention.


[4] Wiring method

(1) Wiring cautions

Use crimp-style terminals for connecting external devices such as limit switches and solenoid valves with input/output module. Select crimp-style terminals referring the dimensions below.



(2) Connecting communication cables




Note

- ★ Use the recommended twisted pair shield cable for wiring to the terminals L₁, L₂, and SHIELD. When wiring the shield line to the terminal block, it is convenient to relay the twisted cable with 0.5 mm² at the outside of the shield cable.
- ★ When installing a slave module in a new location or otherwise moving it, be careful that the communication cable is not excessively stressed or bent.
- ★ Cables from the shield should be kept as short as possible (below 30 mm).
- ★ Ground the slave module's FG terminal (frame ground terminal) with a twisted cable of about 0.5 mm² using the SHIELD terminal. From FG terminal, ground to the control panel chassis with a cable not longer than 150 mm.

A1


(3) Power supply wiring

Twist DC power input lines with each other. As DC input power supply uses a insulation type DC/DC converter inside the module, it is also applicable as power for input signal or output signal.




Note

- ★ In case of sharing this power with load driving power for DC input/output signal, note wiring and noise prevention method.
- ★ FG terminal of slave module is sure to connect with ground through base by cable below 150 mm. It is also used as ground for the DC/DC converter.
- ★ When DC power is supplied to a slave module positioned away from it, provide fuse elements for the DC power supply and each module respectively. Be careful for voltage drop due to long distance wiring.



<Reference> Power voltage and line resistance
 DC power voltage (V_1) =
 $24V + \text{slave module current} \times \text{line resistance} \times 2 \times \text{wire length (km)}$




Line resistance

Nominal sectional area	0.3 mm ²	61.9 ohm/km
	0.5 mm ²	37.1 ohm/km
	0.75 mm ²	24.8 ohm/km

(4) Wiring input signal cable

■ DC input (ZW-82N)


DC power supply : 12/24 VDC



(5) Wiring output signal cable

■ Transistor output (ZW-82S)

DC power supply : 12/24 VDC
Fuse element : 125 VAC, 3A
(on the market)



※Be sure to provide a fuse element for the slave module so as not to burn it out.

- In a DC output module, the (-) pole of external power supply and the (-) pole of DC power are conductive, and be sure to connect wiring to COM (-) terminal.

A1

[5] Error and treatment

You can see the self-diagnosis results by the indicator lamps.

Indicator lamp	Display meaning	Lighting condition	Reset method
RUN	In operation	Slave station normal operation	—
ERROR	Error	• Slave station switch setting error	• Set slave station switch again.
		• Communication error	• Check communication cable.
		• PC stopped	• Operate PC.
		• Slave module defective	• Replace slave module .
RESET	Reset	Note	—
HOLD	Hold	• At master station HALT relay "ON."	—
0 to 7	Input indicator lamp	Comes on when the input signal to the slave module is "ON."	—
	Output indicator lamp	Lights when output signal from PC is "ON".	—

Operation description		Indicator lamp				Reset method	Priority order
		In operation RUN	Error ERROR	Input	Output		
Normal operation	No control input	●		"ON", "OFF" by input signal	Changes due to signal from PC	—	4
	Reset input Note	●			All points "OFF"		
	Hold input Note	●			Output hold		
	Reset and hold input Note	●			All points "OFF"	Reset input is given priority.	
	Output prohibit switch "ON"	●					
Abnormal operation	Slave module error		●	Holding state before abnormality	Replace slave module.	1	
	Switch setting error		●		Set address switch again.		
	Communication suspended	●	●		PC operation	2	
	Communication error (output only)	●	●		Check communication cable. Replace slave module.	3	

●: Lighting, ●: Blinks

Note

- ★ The RESET lamp lights ON only when ZW-31LM is used for master module.
- ★ The HOLD lamp lights ON when JW-31LM/JW-23LM/JW-23LMH are used for master module as synchronizing to internal relay, and also lights ON with CHECK relay "ON" in the case of mode 3 and mode 6.

[6] Specifications

(1) General specifications


Item	Specifications
Storage temperature	-20 to +70°C
Ambient operation temperature	0 to +55°C
Ambient humidity	35 to 90%RH (No condensation)
Vibration resistance	Conforming to JIS-C-0911 (2 hours each in X, Y, Z directions)
Shock resistance	Conforming to JIS-C-0912
Allowable power voltage	24 VDC ± 15% (ripple factor: less than 5%), power source for logic circuit
Power consumption current	100 mA (24 VDC)
Weight	Approx. 300 g (ZW-82N, ZW-82S)

(2) Communication specifications

Item	Specifications
Data transfer rate	EIA RS485 or equivalent
Transfer rate	172.8 k bits/s
Transfer format	Asynchronous system
Coding method	NRZ (Non Return to Zero)
Frame check	Parity check and reverse-double verification
Synchronous mode	Asynchronous
Transfer mode	Time sharing cyclic digital system
Communication line	Party line
	Shielded twisted pair cable
	Cable total length : 1 km max.

(3) Outside dimensions (same for both input and output module)

(Unit: mm)



A1



(4) Specification of each module

① ZW-82N (12/24 VDC input module)

Item	Specifications
No. of input points	8 points
No. of slave station occupied bytes	1 byte
Rated input voltage	12/24 VDC ※
Max. input voltage	26.4 VDC
Rated input current	10.5 mA (at TYP. 24 VDC), 5.5 mA (at TYP. 12 VDC)
Input voltage level	ON level : 10 V or less (at ripple lower limit voltage) OFF level: 6 V or up (at ripple upper limit voltage)
Input current level	ON level : 3.5 mA or less, OFF level: 1.5 mA or up
Input impedance	2.3 k ohm (TYP.)
Response time	OFF → ON: 30 ms or less (12/24 VDC) ON → OFF: 30 ms or less (12/24 VDC)
DC power consumption with current (24 VDC)	Max. 100 mA (power for logic circuit)
Operation indication	Light at ON (8 pcs. of LED)
Connection terminal	Terminal block 8P x 2 pcs.
Applicable wire	1.25 mm ² or less
Ambient temperature, humidity	0 to 55°C, 35 to 90%RH
Dielectric strength	250 VAC, 1 minute (between input terminal, power input terminal and secondary circuit)
Insulation resistance	500 VDC, 10 M ohm or up (between input terminal, power input terminal and secondary circuit)
Insulation system	By photo-coupler
Common terminal	1 common per 8 points

Outside connection drawings

Surface view




※ Full wave rectified DC power without smoothing cannot be used. Ripple factor should be less than 5% in 12 VDC and less than 15% in 24 VDC.

② ZW-82S (12/24 VDC output module)

Item	Specifications
No. of output points	8 points
No. of slave station occupied bytes	1 byte
Rated output voltage	12/24 VDC
Allowable output voltage	10 to 30 VDC
Rated max. output current	0.3 A
Surge ON current	Output element capacity: 1 A (PULSE PW = 20 ms, DUTY = 1/2)
Leakage current	0.1 mA or less
ON voltage	0.5 V or less (0.3 A)
Response time	OFF → ON: 1 ms or less, ON → OFF: 1 ms or less ※
DC power consumption with current (24 VDC)	Max. 100 mA (power for logic circuit)
External supply power (10 to 30 VDC)	Max. 5 mA/point
Operation indication	Light at ON (8 pcs. of LED)
Connection terminal	Terminal block 8P x 2 pcs.
Applicable wire	1.25 mm ² or less
Ambient temperature, humidity	0 to 55°C, 35 to 90%RH
Dielectric strength	250 VAC, 1 minute (between output terminal, power input terminal, and secondary circuit)
Insulation resistance	500 VDC, 10 M-ohm or up (between output terminal, power input terminal, and secondary circuit)
Insulation system	By photo-coupler
Common terminal	1 common per 8 points

Outside connection drawings



Surface view



A1


Appendix 1-2 ZW-161N/162N/161S/162S/164S/162M

[1] Name and function of each part



- ① Indicator lamp
Display each operation condition. (See as below)
- ② Terminal block cover (integral with case)
Protective cover for terminal block
Detachable by cutting off fixing portion.
- ③ Switch cover
Protective cover of station number (ST No.) setting switch ④ and mode setting switch ⑥
- ④ Station number (ST No.) setting switch
Set the station number of slave module.
- ⑤ Terminal block
Connect power source wire, signal wire and other cables.
- ⑥ Mode switch
Switch to set operation mode of slave module.
- ⑦ Module retention hole (4φ)
Mounting holes of M3 screws
- ⑧ Rating plate
- ⑨ DIN rail lever
For detaching from and attaching to DIN lever.

[Indicator lamp]



(Indicator lamps are common to all models.)

Lamp name	Color	Operation
Run lamp	Green	Lighting during normal operation
Error lamp	Red	Lights up when slave station is error or when impossible to communicate with the master station.
24 VDC power lamp	Green	Light when the DC input power source is turned "ON."
Input, output lamps	Red	Light when input and output are "ON."

The 24 VDC power lamp does not light when the fuse of DC input power supply is blown the polarity of power source is wrong.


[2] Setting switch

Before setting the switch, turn OFF the power supply to the PC. Switch setting without turning OFF the power supply may cause malfunction.


(1) Address switch (ST No.)

Set slave station number (ST No.).

- Set from "01" in octal notation.
- Set which byte of the "I/O link area" in the master module is used.



Example: When using two 16 points slave module and one 8 points slave module:



Note

★ Duplicate setting of slave station addresses will result in a malfunction.

Duplicate setting	Operation
If two input modules have the same address	Unspecified input data
If an input module and an output module have the same address	Unspecified data and output module condition
If two output modules have the same address	Output of same data


★ The slave station address of the LCD terminal Z-SM10 shall be set in decimal notation.

A1


(2) Mode setting switch

Sets termination resistance, function, and other items.

Set condition at delivery as an output module




Set condition at delivery as an input module



① Termination resistance

- When setting termination resistance switches, those for stations on the ends of I/O link lines should be "ON," and all other stations should be "OFF."
- The delivery setting is "ON."
- Setting example:
In the diagram below, slave station 03_(B) and the master station are set to "ON," while the other stations are set to "OFF."



② Function setting switch

- Sets "OFF: I/O link" as communication function.
- The delivery setting is "OFF."
- Module will not operate if turned "ON."

③ Output hold setting switch (on output module only)

- When the I/O link communication is error, set the operation at the slave module side. If there is no communication from the master module for more than 1 second, it is judged that the communication is suspended.
The communication is also suspended when the master module HALT relay is "ON."

Set value	Function	Description
ON	Reset	All outputs are "OFF" when communication is suspended.
OFF	Hold	Output before suspension is held when communication is suspended. ※

※ When the CPU is error (when the watchdog timer is actuated), all outputs are "OFF."

④ Output prohibit setting switch (on output module only)

- This is the communication test switch of output module.

Set value	Function	Description
ON	Permit	Lamp of output module and output element are "ON/OFF" depending on the output signal of PC.
OFF	Hold	Output elements are all "OFF" regardless of PC output signal.


A1

[3] Installation method

(1) Installation


Avoid keeping slave module in the following condition.

- Direct sunlight.
- Ambient temperatures below 0°C and over 55°C.
- No condensation due to rapid temperature variation.
- Relative humidity which exceeds 35 to 90%.
- Corrosive and flammable gases.
- Dusts, iron, and salty conditions.
- Vibration and shock producing and transferring positions.
- Peripheral space needed in 5 directions for ventilation and wiring.





- Install in one of the following 4 directions, which afford good cooling.

Horizontal mounting



Vertical mounting




- Being not designed for dust and water proof construction, install in an enclosed panel.
- Avoid installation just above high calorie heat generating devices (heaters, transformers, high capacity resistance etc.) Also avoid to install other equipment close to slave module.
- Avoid installation in a box in which high voltage device is installed.
- As much as possible keep away from high voltage cables and power cables.
- Install on a good conductivity metal plated panel instead of painted one for easy grounding and better noise tolerance.
- Use zinc plated retention screws of M3 for installing slave module.

A1

(2) When using fixing screws

- Use 2 galvanized screws of M3-10.
- Tighten securely to a torque of 5 kgf•cm or less.

■ Installation procedure





- ① Drill M3 tap holes in the control panel for installation as shown at left.
- ② Tighten fixing screws (M3-10, 2 pieces) with a phillips screwdriver, and fix I/O link slave module.

(3) When using DIN rail

- The slave module can be attached to or detached from the 35 mm wide DIN rail instantly.
- Not applicable to DIN rail with the width exceeding or less than 35 mm.


(Unit: mm)



- Using DIN rail lever, fix securely to DIN rail.

A1


■ Installation procedure




- ① Match the claw of the back side of the I/O link slave module with DIN rail.
- ② Push the lower side of the I/O link slave module to DIN rail.

Reference

When installing in the vertical direction, use a bracket to prevent from dropping off due to vibration.



■ Dismounting procedure




- ① Lower the groove of DIN rail lever at the back side of I/O link slave module with slot screwdriver, and lift the entire I/O link slave module, then it is detached from the DIN rail.

A1


[4] Wiring method

(1) Wiring cautions

- Use crimp-style terminals for connections to the limit switch, solenoid valve, and other external devices.



(2) Connecting communication cables




Note

- ★ For wiring to L₁, L₂, and SHIELD terminals, use our recommended twisted pair wire with shield. For shielding of the shield wire, relay with a twisted air of about 0.5 mm² outside, and then wiring to the terminal block will be easier.
- ★ Keep the wire coming out of the shield as short as possible (30 mm or less), and connect to SHIELD terminal.
- ★ To not connect signal cables to terminals other than the L₁, L₂, or SHIELD terminals. Ground the I/O link slave module's FG terminal (frame ground terminal) with a twisted cable of about 0.5 mm² using the SHIELD terminal. Attach a ground wire no longer than 300 mm between the FG terminal and the control panel chassis.


(3) Power supply wiring

- Twist DC power input lines with each other. As DC input power supply uses an insulation type DC/DC converter inside the module, it is also applicable as power for input signal or output signal.




Note

- ★ In case of sharing this power with load driving power for DC input/output signal, note wiring and noise prevention method.
- ★ Be sure that the I/O link slave module's FG terminal is grounded through the control panel. It is also used as ground for the DC/DC converter.
- ★ When DC power is supplied to I/O link slave module positioned away from it, provide fuse elements for the DC power supply and each module respectively. Be careful for voltage drop due to long distance wiring.



<Reference> Power voltage and line resistance

DC power voltage (V_1) =
 $24V + \text{slave module current} \times \text{line resistance} \times 2 \times \text{wire length (km)}$



Line resistance

Nominal sectional area 0.3 mm² 61.9 ohm/km
 0.5 mm² 37.1 ohm/km
 0.75 mm² 24.8 ohm/km

A1


[5] Error and treatment

You can see the self-diagnosis results by the indicator lamp.

Indicator lamp	Display meaning	Lighting condition	Reset method
RUN	In operation	Slave station normal operation	—
ERROR	Error	• Slave station switch setting error	• Set slave station switch again.
		• Communication error	• Check communication cable.
		• PC stopped	• Operate PC.
		• Slave module defective	• Replace slave module.
0 to 7	Input indicator lamp	Comes on when the input signal to the slave module is "ON."	—
	Output indicator lamp	Lights when output signal from PC is "ON."	—

Operation description	Indicator lamp				Reset method	Priority order
	In operation RUN	Error ERROR	Input	Output		
Normal operation	No control input	●	"ON", "OFF" by input signal	Changes due to signal from PC	—	4
	Reset input	●		All points "OFF"		
	Hold input	●		Output hold		
	Reset and hold input	●		All points "OFF"		
	Output prohibit switch "ON"	●				
Abnormal operation	Slave module error		●	Reset input is given priority.	Replace slave module.	1
	Switch setting error		●		Set address switch again.	
	Communication suspended	●	●	Holding state before abnormality	PC operation	2
	Communication error (output only)	●	●		Check communication cable. Replace slave module.	3

●: Lighting, ●: Blinks



(Indicator lamps are common to all models.)

A1

[6] Specifications

(1) General specifications


Item	Specifications
Storage temperature	-20 to +70°C
Ambient operation temperature	0 to +55°C
Ambient humidity	35 to 90%RH (No condensation)
Vibration resistance	Conforming to JIS-C-0911, amplification and acceleration 0.075 mm (10 to 55 Hz), 1 G (55 to 150 Hz), vibration frequency 10 to 150 to 10 Hz (8 min./1 sweep), 2 hours each in X, Y, Z directions (15 times of sweep)
Shock resistance	Conforming to JIS-C-0912 (10 G, 3 times each in X, Y, Z directions)
Allowable power voltage	24 VDC \pm 10% (containing ripple factor), power source for logic circuit
Operation display	Lights at ON (16 LEDs)
Connection terminal	38 P and 5 P (M 3.5 \times 7 screws)
Applicable wire	1.25 mm ² or less

(2) Communication specifications

Item	Specifications
Data transfer rate	EIA RS485 or equivalent
Transfer rate	172.8 k bits/s
Transfer format	Asynchronous system
Coding method	NRZ (Non Return to Zero)
Frame check	Parity check and reverse-double verification
Synchronous mode	Asynchronous
Transfer mode	Time sharing cyclic digital system
Communication line	Party line
	Shielded twisted pair cable
	Cable total length : 1 km max.

(3) Outside dimensions

Outline dimensions are common to all models.




A1

(4) Specifications of each module

① ZW-161N (100 VAC input module)


Item	Specifications
No. of input points	16 points
No. of slave station occupied bytes	2 bytes
Rated input voltage	100 to 120 VAC (50 to 60 Hz)
Allowable input voltage	85 to 132 VAC (50/60 Hz, waveform distortion: 5% or less)
Rated input current	10 mA (at TYP. 100 VAC, 60 Hz), 8.3 mA (at TYP. 100 VAC, 50 Hz)
Input voltage level	ON level: 80 V or less, OFF level: 30 V or more
Input current level	ON level: 7 mA or less, OFF level: 3 mA or more
Input impedance	10 k ohm (TYP.) 60 Hz, 12 kΩ (TYP.) 50 Hz
Surge current	Max. 300 mA, 0.3 ms (132 VAC, at peak ON)
Response time (module alone)	OFF → ON: 30 ms or less ON → OFF: 40 ms or less
DC power consumption with current (24 VDC)	Max. 100 mA (power for logic circuit, 24 VDC±10%, containing ripple factor)
Rated fuse	500 mA for DC power (unable replacement)
Dielectric strength	1500 VAC, 1 minute (between input terminal, DC power terminal, and secondary circuit) 250 VAC, 1 minute (between DC power terminal and secondary circuit)
Insulation resistance	500 VDC, 10 M ohm or up (between input terminal, DC power terminal and secondary circuit)
Insulation system	By photo-coupler
Common terminal	1 common per 8 points
Weight	Approx. 400 g

Outside connection drawings



• "COM1" is assigned at I/O link master module lower number of communication area.

Surface view




A1

② ZW-162N (12/24 VAC input module)


Item	Specifications
No. of input points	16 points
No. of slave station occupied bytes	2 bytes
Rated input voltage	12/24 VDC
Allowable input voltage	10 to 26.4 VDC (includes ripple factor at 12/24 VDC)
Rated input current	8 mA (at TYP. 24 VDC), 3.5 mA (at TYP. 12 VDC)
Input voltage level	ON level: 10 V or less, OFF level: 6 V or more
Input current level	ON level: 3.5 mA or less, OFF level: 1.5 mA or more
Input impedance	3 k ohm (TYP.)
Surge current	—
Response time (module alone)	OFF → ON: 30 ms or less (12/24 VDC) ON → OFF: 30 ms or less (12/24 VDC)
DC power consumption with current (24 VDC)	Max. 100 mA (power for logic circuit, 24 VDC±10%, containing ripple factor)
Rated fuse	500 mA for DC power (unable replacement)
Dielectric strength	1500 VAC, 1 minute (between input terminal, DC power terminal, and secondary circuit) 250 VAC, 1 minute (between DC power terminal and secondary circuit)
Insulation resistance	500 VDC, 10 M ohm or up (between input terminal, DC power terminal, and secondary circuit)
Insulation system	By photo-coupler
Common terminal	1 common per 8 points
Weight	Approx. 350 g

Outside connection drawings



• "C1" is assigned at I/O link master module lower number of communication area.

Surface view




A1

③ ZW-161S (triac output module)


Item	Specifications
No. of output points	16 points
No. of slave station occupied bytes	2 bytes
Rated load voltage	100 to 120 VAC (50/60 Hz)
Allowable load voltage	15 to 132 VAC (50/60 Hz, waveform distortion: 5% or less)
Rated max. output current	0.5 A/point, 2 A/common
Surge ON current	Output element capacity: 6 A (100 ms)
※ Min. load current	10 mA or less
Leakage current	1.5 mA or less
ON voltage	2 V or less (0.5 A)
Response time	OFF → ON: 1 ms or less, ON → OFF: 1/2 power frequency +1 ms or less
Surge killer	CR absorber, varistor
Rated fuse	500 mA for DC power (unable replacement), 2 A for load power (unable replacement)
DC power consumption with current (24 VDC)	Max. 150 mA (power for logic circuit 24 VDC ±10%, containing ripple factor)
Dielectric strength	1500 VAC, 1 minute (between output terminal, power terminal and secondary circuit) 250 VAC, 1 minute (between DC power terminal and secondary circuit)
Insulation resistance	500 VDC, 10 M ohm or up (between output terminal, power terminal and secondary circuit)
Insulation system	By photo-coupler
Common terminal	1 common per 8 points
Weight	Approx. 500 g

Outside connection drawings



- "COM1" is assigned at I/O link master module lower number of communication area.
- We recommend to install applicable fuse to every output for safety.

Surface view




※ When the load current (in holding) is smaller than the minimum load current of 10 mA, it may not be turned OFF depending on the load characteristic. In such a case, connect a bleeder resistance parallel to the load as shown above, and increase the load current more than 10 mA.

④ ZW-162S (transistor output module)


Item	Specifications
No. of output points	16 points
No. of slave station occupied bytes	2 bytes
Rated load voltage	12/24 VAC
Allowable load voltage	10 to 30 VAC
Rated max. output current	0.3 A/point, 2 A/common
Surge ON current	Output element capacity: 2 A (100 ms)
Min. load current	—
Leakage current	0.1 mA or less
ON voltage	0.5 V or less (0.3 A)
※ Response time	OFF → ON: 1 ms or less, ON → OFF: 1 ms or less (resistance load)
Surge killer	Zener diode
Rated fuse	500 mA for DC power (unable replacement), 2 A for load power (unable replacement)
DC power consumption with current (24 VDC)	Max. 100 mA (power for logic circuit 24 VDC ±10%, containing ripple factor)
Dielectric strength	1500 VAC, 1 minute (between output terminal, power terminal and secondary circuit) 250 VAC, 1 minute (between DC power terminal and secondary circuit)
Insulation resistance	500 VDC, 10 M ohm or up (between output terminal, power terminal and secondary circuit)
Insulation system	By photo-coupler
Common terminal	1 common per 8 points
Weight	Approx. 400 g

Outside connection drawings



- "C1" is assigned at I/O link master module lower number of communication area.
- We recommend to install applicable fuse to every output for safety.

Surface view





※ When induction load is applied, the switching time from "ON" to "OFF" may be delayed 1 second or more by inductance of load.

⑤ ZW-164S (relay output module)

Item		Specifications
No. of output points		16 points
No. of occupied bytes		2 bytes
Max, open-close voltage, current		264 VAC/30 VDC, 2 A (resistance load)
Min, load		5 VDC, 1 mA
Operation life	Mechanical	20,000,000 times or more
	Electrical	1. Max, open-close voltage current resistance 100,000 times or more 2. Inductive load: 250 VAC, 0.5 A (COS ϕ = 0.4) 300,000 times or more 3. Inductive load: 30 VDC, 0.5 A (T = 7 ms) 300,000 times or more
Response time		OFF \rightarrow ON: 10 ms or less (resistance load) ON \rightarrow OFF: 10 ms or less (resistance load)
Surge killer		—
Rated fuse		500 mA for DC power (unable replacement)
DC power consumption with current (24 VDC)		Max. 200 mA
Dielectric strength		1500 VAC, 1 minute (between output terminal, DC power terminal and secondary circuit) 250 VAC, 1 minute (between DC power terminal and secondary circuit)
Insulation resistance		500 VDC, 10 M ohm or up (between output terminal, DC power terminal and secondary circuit)
Common terminal		1 common per 1 point
Weight		Approx. 400 g

Outside connection drawings

Surface view




- We recommend to install applicable fuse to every output for safety operation.

A1

⑤ ZW-162M (transistor output module, 12/24 VDC input module)


Item		Specifications
No. of slave station occupied bytes		2 bytes
Output specification	No. of output points	8 points
	Rated load voltage	12/24 VAC
	Allowable load voltage	10 to 30 VAC
	Rated max. output power	0.3 A/point, 2 A/common
	Surge ON current	Output element capacity: 2 A (100 ms)
	Leakage current	0.1 mA or less
	ON voltage	0.5 V or less (0.3 A)
	※ Response time	OFF → ON: 1 ms or less, ON → OFF: 1 ms or less (resistance load)
Surge killer		Zener diode
Input specification	No. of input point	8 points
	Rated input voltage	12/24 VDC
	Allowable input voltage	10 to 26.4 VDC (includes ripple factor at 12/24 VDC)
	Rated input current	8 mA (at TYP. 24 VDC), 3.5 mA (at TYP. 12 VDC)
	Input voltage level	ON level: 10 V or less, OFF level: 6 V or up
	Input current level	ON level: 3.5 mA or less, OFF level: 1.5 mA or up
	Input impedance	3 k ohm (TYP.)
	Surge current	—
Response time (Module alone)		OFF → ON: 30 ms or less (12/24 VDC) ON → OFF: 30 ms or less (12/24 VDC)
Rated fuse		500 mA for DC power (unable replacement), 2 A for load power (unable replacement)
DC power consumption with current (24 VDC)		Max. 100 mA (power for logic circuit 24 VDC ±10%, containing ripple factor)
Dielectric strength		1500 VAC, 1 minute (between input/output terminal, power input terminal, and secondary circuit) 250 VAC, 1 minute (between DC power terminal, and secondary circuit)
Insulation resistance		500 VDC, 10 M ohm or up (between input/output terminal, power input terminal and secondary circuit)
Insulation system		By photo-coupler
Common terminal		Output: 8 pts./common, Input: 8 pts./common
Weight		Approx. 400 g

Outside connection drawings



- Output is assigned at I/O link master module lower number of communication area.
- We recommend to install applicable fuse to every output for safety operation.

Surface view




※ When induction load is applied, the switching time from "ON" to "OFF" may be delayed 1 second or more by inductance of load.

A1


Appendix 1-3 ZW-164NH/162SH/162MH

[1] Name and function of each part




- ① Indicator lamp
Display each operation condition. (See next page)
- ② Terminal block cover
Protect the terminal block
- ③ Terminal block (26 p detachable M 3.5 × 7 screws)
Connect power source wire, signal wire and other cables.
- ④ Module retention hole (ϕ 4: 2 places)
Holes to attach the slave module to the control panel using M3 screws.
- ⑤ DIN rail lever
Detaching for DIN rail.
- ⑥ ST. No. switch, MODE switch
Set slave station number, termination resistance, function, output hold, and output prohibit.
(See [2] Setting switch).


[Indicator lamp]
· ZW-164NH



· ZW-162SH



· ZW-162MH




Lamp name	Color	Operation contents
RUN	Green	Lighting during normal operation
ERROR	Red	Lights up when slave station is error or when impossible to communicate with the master station.
POWER	Green	It is lit when the 24 VDC power is ON. · The POWER lamp will not be lit when the DC power fuse is blown, or if the power source polarity is reversed.
0 to 7 (2 places)	Red	· When the ZW-164NH is used, this lamp will light when any of the input signals (16 points) is ON · When the ZW-162SH is used, this lamp will light when any of the output signals (16 points) is ON · When the ZW-162MH is used, this lamp will light when any of the I/O signals (8 points) is ON
FUSE	Red	Lights when the common fuse for the output circuit (inside the module) is blown, or the load power is OFF. · There is a FUSE lamp on the ZW-162SH/162MH models, but not on the ZW-164NH model.

A1

[2] Setting switch

Before setting the switch, turn OFF the power supply to the I/O link system. Switch setting without turning OFF the power supply may cause malfunction.

Set station number, termination resistance, function, output hold (ZW-162SH/162MH), and output prohibit (ZW-162SH/162MH) by using switch of ZW-164NH/162SH/162MH.



Switch		Setting details	Setting when delivered
ST. No.	40	Enter slave station number - Enter starting from "01," using octal notation - Assign which byte will be used in the I/O link area of the master station	All OFF
	20		
	10		
	4		
	2		
	1		
MODE switch	LT	Termination resistance - Turn ON this switch at both ends of the I/O link circuit. Turn this switch OFF on all other stations.	ON
	FUNC	Function selection - Select "OFF: I/O link" for the communication function. (ON: M-net function)	OFF
	HOLD	Latched output - Set the operation of the slave station module, when an I/O link communication error occurs. If there is no communication from the master module for more than one second, it will be treated as a communication interruption. If the master module HALT relay is ON, the communication will also be interrupted. ON (reset): Turn OFF all outputs when communication interruption OFF (latched): Latch the output condition before interruption. When a CPU error occurs (the watchdog timer times out) the all outputs turn OFF.	OFF
	PO	Output prohibited - A switch to test communication of the output module. ON (permitted): The output module lamps and output elements turn ON and OFF according to the output signal conditions in the PC. OFF (latched): All elements turn OFF regardless of the output signal conditions in the PC.	ON

A1

[3] Installation method


Install the ZW-164NH/162SH/162MH following the precautions below in order to get the best use of these stations.

(1) Installation conditions

- Ventilation holes are provided in order to keep the internal temperature from rising. Do not block these holes.
- Slave module is not designed for dust and water proof construction, install in an enclosed control box.
- Avoid installation just above high calorie heat generating devices (heaters, transformers, high capacity resistance etc.) Also avoid to install other equipment close to slave module.
- Avoid installation in a box in which high voltage device is installed.
- As much as possible keep away from high voltage cables and power cables.
- Use a metallic chassis in order to get a good ground and suppress noise.


(2) Installation directions

- Install in one of the following 5 directions, which afford good cooling.




(3) Installation space

Make sure to provide the spacings shown below, between the slave module and the wiring ducts, to allow proper heat dissipation.




A1

Make sure to provide the spacings shown below when installing more than one slave module.



* Leave spaces for wiring (2 places)




(4) Installation method

Use screws or a DIN rail to install the slave module.


① Using screws

1. Drill M3 tapped holes in a control box, referring to the installation dimensions shown below.



2. Tighten the two screws using a Phillips screwdriver to secure the slave module.


- Use 2 zinc plated M3-10 screws.
- Tighten them to 5 kgf-cm of torque, or less.




A1

② Using a DIN rail


The slave module can be attached to a DIN rail having rail 35 mm in width.




1. Hook the claws on the back of the slave module on a DIN rail, and press in the direction shown by the arrow.



2. To remove the slave station from the DIN rail, lower the DIN rail lever groove using a flat blade screwdriver, and lift the module. Then the slave station will be free of the DIN rail.




3. If you want to install the slave module horizontally, use a bracket in order to prevent it from falling off due to vibration.




A1

[4] Wiring method

Use crimp-style terminals to connect the ZW-164NH/162SH/162MH to other equipment. Select the crimp-style terminal size by referring to the dimensions given below.



(f) Connecting the communication lines



1. Make sure to use the recommended shielded twisted pair cables shown below to wire L1, L2, and SHLD (shield line). The shield can be wired easily by using 0.5 mm² twisted cable at outside the cable.


Recommended cables	
Hitachi cable	S-IREV-SW2*0.5, S-IREV-SB2*0.5
Fujikura Electric	RG-22B/U

Do not install the slave module where mechanical stress or bending force will be placed on the signal lines.

2. The lead wire from the shield should be less than 30 mm long. Connect it to the SHLD terminal.
3. Do not connect any signal line to the NC terminal. Do not use it as a relay terminal.
4. The SHLD and FG terminals are connected by a shorting tab when delivered. Connect the FG terminal to the control box chassis using a ground cable (accessory) .

A1

(2) Wiring of power lines



1. Twist DC power input lines with each other. As DC input power supply uses a insulation type DC/DC converter inside the module, it is also applicable as power for input signal or output signal. If you use a DC power input in common with the input signal or output signal power source, short circuit the COM.A side using a shorting tab (accessory).


Shorting tab (accessory)	Model	Shorting positions
· Upper row of the terminal block 	ZW-164NH	Connect the 24 V and COM.A terminals on the terminal block
	ZW-162SH	Connect the 24 V and (+) A, B terminals on the terminal block
	ZW-162MH	Connect the 24 V and (+) A terminals on the terminal block
· Lower row of the terminal block 	ZW-162SH	Connect the 0 V and COM.A terminals on the terminal block
	ZW-162MH	Connect the 0 V and COM.A terminals on the terminal block

2. In case of sharing this power with load during power for DC input/output signal, note wiring and noise prevention method.
3. Be sure that the I/O link slave module's FG terminal is grounded through the grounding terminal of control box.

It is also used as ground for the DC/DC converter.

Reference

When DC power is supplied to slave module positioned away from it, provide fuse elements for baking prevention of wiriness in DC power supply and each module respectively. Be careful for voltage drop due to long distance wiring.



<Reference> Power voltage and line resistance	Line resistance
DC power voltage ($V_1 - V_2$) = current \times line resistance $\times 2 \times$ wire length (km)	Nominal sectional area 0.75 mm ² 24.8 ohm/km
	1.25 mm ² 14.7 ohm/km
	2 mm ² 9.53 ohm/km

- If you set the DC power to 26.4 V, make sure the voltage drop is less than 6 V.
 $26.4 \text{ V} - 20.4 \text{ V} = 6 \text{ V}$ (20.4 V : Minimum operating voltage for the slave module.)

[5] Error and treatment

You can see the self-diagnosis results by the indicator lamp.
See page 61 for position of indicator lamp.

Indicator lamp	Display meaning	Lighting condition	Reset method
RUN	In operation	Slave station normal operation	—
ERROR	Error	Slave station switch setting error	Set slave station switch again.
		Communication error	Check communication cable.
		PC stopping	Operate PC.
		Slave module defective	Replace slave module .
0 to 7 [2] places	Input indicator lamp	Comes on when the input signal to the slave module is "ON."	—
	Output indicator lamp	Lights when output signal from PC is "ON".	
Fuse [ZW-162SH] [ZW-162MH]	Fuse	When the common fuse of the output circuit (inside the module) is blown.	Replace slave module.
		When load power is OFF	Check the load power.

Operation description	Indicator lamp				Reset method	Priority order	
	In operation RUN	Error ERROR	Input	Output			
Normal operation	Turn OFF output prohibition switch	●		"ON", "OFF" by input signal	Changes due to signal from PC	—	4
	Turn ON output prohibition switch	●					
Abnormal operation	Slave module error		●	"ON", "OFF" by input signal	All points "OFF"	Replace slave module.	1
	Switch setting error		●				
	Communication suspended	●	●		Holding state before abnormality	PC operation.	3
	Communication error (output only)	●	●			Check communication cable. Replace slave module.	

●: Lighting, ○: Blinks

A1

[6] Specifications

(1) General specifications


Item	Specifications
Allowable power voltage	24 VDC (+10%, -15% : ripple)
Power consumption/current	1.4 W/70 mA max.
Storage temperature	-20 to +70°C
Ambient operation temperature	0 to +55°C
Ambient humidity	35 to 90%RH (Not to condense dew)
Vibration resistance	Conforming to JIS-C-0911 (2 hours each in X, Y, Z directions)
Shock resistance	Conforming to JIS-C-0912 (10 G, 3 times each in X, Y, Z directions)
Withstand voltage	1000 VAC for one minute (between input/output terminals, DC power input terminal, and secondary circuit)
Insulation resistance	500 VDC, 10 M-ohm min. ((between input/output terminals, DC power input terminal, and secondary circuit)
Insulation method	Photo-coupler
External line connection	26 P detachable terminal block (M 3.5 × 7 screws)
Weight	Approximately 320 g
Accessories	One grounding cable, one user's manual, short tab (one for ZW-164NH, two for ZW-162SH/162MH)

(2) Communication specifications

Item	Specifications
Data transfer rate	EIA RS485 or equivalent
Transfer rate	345.6 k bits/s, 172.8 k bits/s (changes automatically according to the data transfer speed of master station.)
Transfer format	Asynchronous system
Coding method	NRZ (Non Return to Zero)
Frame check	Parity check and reverse-double verification
Synchronous mode	Asynchronous
Transfer mode	Time sharing cyclic digital system
Communication line	Party line
	Shielded twisted pain cable
	Cable total length : 1 km max.

(3) Outside dimensions

Outline dimensions are common to all models.



※ Dimensions when a DIN rail lever is moved.


A1

(4) Specifications of I/O


① ZW-164NH (24 VDC input module)

Item	Specifications
No. of input point	16 points
No. of slave station occupied bytes	2 bytes
Rated input voltage	24 VDC
Allowable input voltage	20.0 to 26.4 VDC Ripple factor: Less than 15%
Rated input current	4.6 mA TYP. (at 24 VDC)
Input voltage level	ON level: 18.0 V or less, OFF level: 8.0 V or more
Input current level	ON level: 3 mA or less, OFF level: 1.5 mA or more
Input impedance	5.2 k ohm TYP.
Surge current	—
Response time (module alone)	OFF → ON: 1.0 ms or less (24 VDC) ON → OFF: 1.5 ms or less (24 VDC)
Common terminal	1 common per 8 points

Outside connection drawings



Surface view




- The "COM.A" is assigned at I/O link master module lower numbers of the communication area.

A1

② ZW-162SH (transistor output module)

Item	Specifications
No. of output points	16 points
No. of slave station occupied bytes	2 bytes
Rated load voltage	24 VDC
Allowable load voltage	20.4 to 26.4 VDC
Rated max. output current	0.3 A/point, 1 A/common
Surge ON current	Output element capacity: 2 A (100 ms)
Min. load current	—
Leakage current	0.1 mA or less
Voltage drop at turning ON	0.5 V or less (0.3 A)
Response time (module alone)	OFF → ON: 1 ms or less ON → OFF: 1 ms or less (resistance load)
Surge killer	Zener diode
Rated fuse	1.25 A (unable replacement) Meltdown detection function is provided (When melted down or load power is turned OFF, the FUSE lamp lights)
Common terminal	1 common per 8 points


Outside connection drawings



※ If you use the side A common line and side B common line with different power sources, connect the negative sides of the both power supplies.

- "COM. A" is assigned at I/O link master module lower number of the communication area.
- We recommend to install applicable fuse to every output for safety.

Surface view




A1

③ ZW-162MH (transistor output, 24 VDC input module)

Item		Specifications
No. of slave station occupied bytes		2 bytes
Output specification	No. of output points	8 points
	Rated load voltage	24 VDC
	Allowable load voltage	20.4 to 26.4 VDC
	Rated max. output power	0.3 A/point, 1 A/common
	Surge ON current	0.5 A (10 ms)
	Minimum load current	—
	Leakage current (when OFF)	0.1 mA or less
	Voltage drop at turning ON	0.5 V or less (0.3 A)
	Response time (module alone)	OFF → ON: 1 ms or less
		ON → OFF: 1 ms or less (resistance load)
	Surge killer	Zener diode
	Rated fuse	Built-in 1.25 A fuse (unable replacement) Meltdown detection function is provided (When melted down or load power is turned OFF, the FUSE lamp lights)
	Common terminal	1 common per 8 points
Input specification	No. of input point	8 points
	Rated input voltage	24 VDC
	Allowable input voltage	20.0 to 26.4 VDC (ripple factor: Less than 15%)
	Rated input current	4.6 mA TYP. (at 24 VDC)
	Input voltage level	ON level: 18.0 V or less, OFF level: 8.0 V or up
	Input current level	ON level: 3 mA or less, OFF level: 1.5 mA or up
	Input impedance	5.2 k ohm (TYP.)
	Surge current	—
	Response time (Module alone)	OFF → ON: 1.0 ms or less (24 VDC)
		ON → OFF: 1.5 ms or less (24 VDC)
Common terminal	1 common line for 8 points (no polarity)	


A1

Outside connection drawings




- "COM.A" is assigned at the output side, and at I/O link master module lower number of the communication area.
- We recommend to install applicable fuse to every output for safety.


Surface view




[Indicator lamp]
· ZW-324NH



· ZW-322SH



· ZW-322MH




Lamp name	Color	Operation contents
RUN	Green	Lighting during normal operation
ERROR	Red	Lights up when slave station is error or when impossible to communicate with the master station.
POWER	Green	It is lit when the 24 VDC power is ON. · The POWER lamp will not be lit when the DC power fuse is blown, or if the power source polarity is reversed.
0 to 7 (4 places)	Red	· When the ZW-324NH is used, this lamp will light when any of the input signals (32 points) is ON · When the ZW-322SH is used, this lamp will light when any of the output signals (32 points) is ON · When the ZW-322MH is used, this lamp will light when any of the I/O signals (16 points) is ON
FUSE	Red	Lights when the common fuse for the output circuit (inside the module) is blown, or the load power is OFF. · There is a FUSE lamp on the ZW-322SH/322MH models, but not on the ZW-324NH model.


[2] Wiring method

(1) Wiring cautions

- Use crimp-style terminals for connections to the limit switch, solenoid valve, and other external devices.



(2) Connecting communication cables




Note

- ★ For wiring to L₁, L₂, and SHIELD terminals, use our recommended twisted pair wire with shield. For shielding of the shield wire, relay with a twisted air of about 0.5 mm² outside, and then wiring to the terminal block will be easier.
- ★ Keep the wire coming out of the shield as short as possible (30 mm or less), and connect to SHIELD terminal.
- ★ Do not connect signal cables to terminals other than the L₁, L₂, or SHIELD terminals. SHIELD and FG terminals are already shorted. Attach a ground wire between the FG terminal and the control panel chassis.


(3) Power supply wiring

Twist DC power input lines with each other. As DC input power supply uses an insulation type DC/DC converter inside the module, it is also applicable as power for input signal or output signal.



Note


- ★ In case of sharing this power with load driving power for DC input/output signal, note wiring and noise prevention method.
- ★ Be sure that the I/O link slave module's FG terminal is grounded through the control panel. It is also used as ground for the DC/DC converter.
- ★ When DC power is supplied to I/O link slave module positioned away from it, provide fuse elements for the DC power supply and each module respectively. Be careful for voltage drop due to long distance wiring



<Reference> Power voltage and line resistance

DC power voltage (V_1) =

$$24V + \text{slave module current} \times \text{line resistance} \times 2 \times \text{wire length (km)}$$




Line resistance

Nominal sectional area	Line resistance (ohm/km)
0.3 mm ²	61.9
0.5 mm ²	37.1
0.75 mm ²	24.8

Reference Terminal block cover

If it is difficult to make the connections, you can raise the terminal block cover and hold it on the module indicator lamps.



- After the completion of the wiring, secure the terminal block cover in its original position.

- The bending portion of the terminal block cover is designed to be bent dozens of times. However, if the terminal block cover breaks at the bending point, you can secure the terminal block cover using the holes shown left.

[3] Specifications

(1) General specifications

Item	Specifications
Allowable power voltage	24 VDC \pm 10% (Ripple factor: Less than 5%), power for logic circuit
Power consumption/current	100 mA max.
Storage temperature	-20 to +70°C
Ambient operation temperature	0 to +55°C
Ambient humidity	35 to 90%RH (Not to condense dew)
Vibration resistance	Conforming to JIS-C-0911 (2 hours each in X, Y, Z directions)
Shock resistance	Conforming to JIS-C-0912 (10 G, 3 times each in X, Y, Z directions)
Withstand voltage	1000 VAC for one minute (between input/output terminals, DC power input terminal, and secondary circuit)
Insulation resistance	500 VDC, 10 M-ohm min. (between input/output terminals, DC power input terminal, and secondary circuit)
Insulation method	Photo-coupler
Weight	Approximately 500 g
Accessories	One grounding cable, one user's manual


(2) Communication specifications

Item	Specifications
Data transfer rate	EIA RS485 or equivalent
Transfer rate	345.6 k bits/s, 172.8 k bits/s (changes automatically according to the data transfer speed of master station.)
Transfer format	Asynchronous system
Coding method	NRZ (Non Return to Zero)
Frame check	Parity check and reverse-double verification
Synchronous mode	Asynchronous
Transfer mode	Time sharing cyclic digital system
Communication line	Party line
	Shielded twisted pair cable
	Cable total length : 1 km max.

(3) Outside dimensions

Outline dimensions are common to all models.

(Unit: mm)




※ Dimensions when a DIN rail lever is moved.

(4) Specifications of I/O


① ZW-324NH (24 VDC input module)

Item	Specifications
No. of input point	32 points
No. of slave station occupied bytes	4 bytes
Rated input voltage	24 VDC
Allowable input voltage	20.0 to 26.4 VDC Ripple factor: Less than 15%
Rated input current	4.6 mA TYP. (at 24 VDC)
Input voltage level	ON level: 18.0 V or less, OFF level: 8.0 V or more
Input current level	ON level: 3 mA or less, OFF level: 1.5 mA or more
Input impedance	5.2 k ohm TYP.
Surge current	—
Response time (module alone)	OFF → ON: 1.0 ms or less (24 VDC) ON → OFF: 1.5 ms or less (24 VDC)
Common terminal	1 common per 16 points

Outside connection drawings



Surface view




- "COM.A" is assigned at I/O link master module lower number of the communication area.

A1


③ ZW-322MH (transistor output, 24 VDC input module)

Item		Specifications
No. of slave station occupied bytes		4 bytes
Output specification	No. of output point	16 points
	Rated load voltage	24 VDC
	Allowable load voltage	10 to 26.4 VDC
	Rated max. output power	0.3 A/point, 2 A/common
	Surge ON current	0.5 A (100 ms)
	Minimum load current	—
	Leakage current (when OFF)	0.1 mA or less
	Voltage drop at turning ON	0.5 V or less (0.3 A)
	Response time (module alone)	OFF → ON: 1 ms or less
		ON → OFF: 1 ms or less (resistance load)
	Surge killer	Zener diode
	Rated fuse	Built-in 2 A fuse (unable replacement) Meltdown detection function is provided (When melted down or load power is turned OFF, the FUSE lamp lights)
	Common terminal	1 common per 16 points
Input specification	No. of input point	16 points
	Rated input voltage	24 VDC
	Allowable input voltage	20.0 to 26.4 VDC (Ripple factor: 15% or less)
	Rated input current	4.6 mA TYP. (at 24 VDC)
	Input voltage level	ON level: 18.0 V or less, OFF level: 8.0 V or up
	Input current level	ON level: 3 mA or less, OFF level: 1.5 mA or up
	Input impedance	5.2 k ohm (TYP.)
	Surge current	—
	Response time (Module alone)	OFF → ON: 1.0 ms or less (24 VDC)
		ON → OFF: 1.5 ms or less (24 VDC)
Common terminal	1 common line for 16 points (no polarity)	

Outside connection drawings




Surface view



- "COM.A" is assigned at the output inside, and at I/O link master module lower numbers of the communication area.
- We recommend to install applicable fuse to every output is recommended for safety.

Appendix 1-5 ZW-84NC/162MC

[1] Name and function of each part



① Indicator lamp
Display each operation condition.
(See the next page)

② Communication/power supply connection (IN)
Connects the communication lines from the master module or the previous slave station module in the line.

③ Communication, power supply connector (OUT)
Connect the communication lines and power lines to the next stage slave module in the line.
If this is the final module, put a cover.

④ Grounding terminal
Connect the class-3 grounding.


⑤ I/O connector
Connect to input equipment when a ZW-84NC is used. Connect to input/output equipment when a ZW-162MC is used.
Put a cover if you do not use this connector.

⑥ Module retention hole ($\phi 4.5$; 4 places)
Holes to attach the slave module to the control panel using M3 screws.

⑦ Switch cover

⑧ Switch cover screws (4)
Loosen and remove to install the switch.


⑨ Switch




See page 85 for setting contents.

A1

[Indicator lamp]
· ZW-84NC



· ZW-162MC



Lamp name	Color	Operation contents
POWER	Green	It is lit when the 24 VDC power is ON. · The POWER lamp will not be lit when the DC power fuse is blown, or if the power source polarity is reversed.
RUN	Green	Lighting during normal operation
ERROR	Red	Lights up when slave station is error or when impossible to communicate with the master station.
FUSE ※	Red	Lights when the fuse for the output circuit is blown OFF.
IN (0 to 7)	Red	This lamp will light when any of the input signals (8 points) is ON
OUT (0 to 7) ※	Red	This lamp will light when any of the output signals (8 points) is ON


※ ZW-84NC does not have FUSE and OUT lamps.

A1

[2] Setting switch

Before setting the switch of ZW-84NC/162MC, turn OFF the power supply to the I/O link system. Switch setting without turning OFF the power supply may cause malfunction.

Set transfer rate, station number, termination resistance, function, output hold (ZW-162MC), and output prohibit (ZW-162MC) by using switch of ZW-84NC/162MC.



Switch	Setting details	Setting when delivered
ST. No. (station number)	40 20 10 4 2 1 Enter slave station number - Enter starting from "01," using octal notation - Assign which byte will be used in the I/O link area of the master module	All OFF
LT (Termination resistance)	Termination resistance - Turn ON this switch at both ends of the I/O link circuit. Turn this switch OFF on all other stations.	ON
FUNC (Functional setting)	Function selection - Select "OFF: I/O link" for the communication function. (ON: M-net function)	OFF
HOLD (Output hold setting)	Latched output - Set the operation of the slave module, when an I/O link communication error occurs. If there is no communication from the master module for more than one second, it will be treated as a communication interruption. If the master module HALT relay is ON, the communication will also be interrupted. ON (reset): Turn OFF all outputs when communication interruption ※ OFF (latched): Latch the output condition before interruption. When a CPU error occurs (the watchdog timer times out) the all outputs turn OFF.	OFF
PO (Output prohibition setting)	Output prohibited - A switch to test communication of the output module. ON (permitted): The output module lamps and output elements turn ON and OFF according to the output signal conditions in the PC. ※ OFF (latched): All elements turn OFF regardless of the output signal conditions in the PC.	ON

※ ZW-84NC does not have HOLD and PO switches. (Invalid the settings)

A1

[3] Installation method

Install the ZW-84NC/162MC following the precautions below in order to get the best use of these stations.


(1) Installation conditions

- Avoid installation just above high calorie heat generating devices (heaters, transformers, high capacity resistance etc.) Also avoid to install other equipment close to slave module.
- Avoid installation in a box in which high voltage device is installed.
- As much as possible keep away from high voltage cables and power cables.


(2) Installation directions

- Install in one of the following directions, which afford good cooling.

Horizontal mounting



Vertical mounting




A1


(3) Installation method

Use M4 screws (2) or a DIN rail to install the slave module.
Tighten to 10 kgf-cm of torque or less.

[Installation dimensions]



Install after considering the dimensions of the communication/power cables, and input/output cables.




[4] Wiring method

(1) Recommended cables and plugs

Use only the recommended items for communication/power cables, and clamps.



(2) Connecting communication/power lines

[Wiring method]




Note: Pins 3, 4, and 5 on the communication/power connector are connected to each other inside the module.

[Pin allocation on the connection/power connector] [ZW-84NC/162MC side]




Pin number	Signal name
1	L1
2	L2
3	SHIELD
4	SHIELD
5	FG
6	24V
7	0V


[Connection drawings for the recommended cable (MRC-SB-5C) and plug]



1. Keep the communication/power cable as far away as possible from high voltage lines and power lines.
2. Provide relay terminal blocks, if required.
3. Make sure to turn OFF the power before inserting or removing the connector.
4. To attach the connector, insert it all the way and screw it down tight. Be careful not to damage the threads.



5. Make sure to connect the ground terminal (FG) to earth through the ground terminal of the control box.



6. Pay attention to the voltage drop in the cable used to supply 24 VDC. The power input voltage at the slave module must be 20.4 V or more.




7. Put a cover on the communication/power connector (OUT) of the final module.

A1

Precautions when wiring power lines

- Do not exceed a 5 A draw on the power line for more than one module.
(If the current draw will exceed 5 A, use a separate cable.)
- The supply current to the slave modules should be less than 1 A total.
A short circuit in external equipment, or a supply current of more than 1 A may blow the internal fuse, and shut off the supply current.
(If the internal fuse is blown, all of the indicator lamps on the slave module will go out. The entire module must be replaced.)

Supply current for the slave modules	ZW-84NC	ZW-162MC
Current consumption of the module (consumed by the module itself)	Max. 100 mA	Max. 110 mA
Input power supply (supplied to external sensors via the input/output connector)	Max. 900 mA	Totally max. 890 mA
Output load (supplied to the external load via the input/output connector)	—	





A1

(3) Input/output signal wiring

[Wiring method]


[Pin allocation on the input/output connector]

An example for connecting a 2-line system sensor




Pin number	Signal name	Remarks
1	24 V	
2	Output	ZW-162MC only
3	0 V	
4	Input	

An example for connecting a 3-line system sensor




An example for connecting a sensor to a lamp (ZW-162MC only)




1. The new JIS standard used in the 3-line system sensor. Note the difference in the connector pin allocation for the 2-line system and the old JIS standard models.
2. PNP current output sensors cannot be used.
3. Use the recommended connector for the sensor connection.
4. Make sure to turn OFF the power before inserting or removing the connector.
5. To attach the connector, insert it all the way and screw it down tight. Be careful not to damage the threads.

Fixing metal when loose



Fixing metal when tight



6. Put a cover on the I/O connector of the final module.

A1

[5] Error and treatment

You can see the self-diagnosis results by the indicator lamp.
See page 84 for position of indicator lamp.

Indicator lamp	Display meaning	Lighting condition	Reset method
RUN	In operation	Slave station normal operation	—
ERROR	Error	Slave station switch setting error	Set slave station switch again.
		Communication error	Check Communication Cable.
		PC stopping	Operate PC.
		Slave module defective	Replace slave module.
IN 0 to 7	Input indicator lamp	Comes ON when the input signal to the slave module is "ON."	—
OUT 0 to 7 (ZW-162MC)	Output indicator lamp	Lights when output signal from PC is "ON".	
Fuse (ZW-162MC)	Fuse	A fuse on the output circuit is blown.	Replace slave module.

Operation description	Indicator lamp				Reset method	Priority order	
	In operation RUN	Error ERROR	Input 0 to 7	Output 0 to 7 (ZW-162MC)			
Normal operation	Turn OFF output prohibition switch	●		"ON", "OFF" by input signal	Changes due to signal from PC	—	4
	Turn ON output prohibition switch	●					
Abnormal operation	Slave module error		●	"ON", "OFF" by input signal	All points "OFF"	Replace slave module	1
	Switch setting error		●				
	Communication suspended	●	●		Holding state before abnormality	PC operation	2
	Communication error (output only)	●	●				

●: Lighting, ○: Blinks

[6] Specifications

(1) General specifications

Item	Specifications
Allowable power voltage	24 VDC (+10%, -15% : Ripple factor; less than 5%)
Power consumption current	ZW-84NC : 100 mA Max, ZW-162MC : 110 mA Max · Current from 24 V power terminal (pin 1) of the input/output connector is not included. · Total current consumption supplied from the 24 V power terminal (pin 1) should be 1 A max.
Storage temperature	-20 to +70°C
Ambient operation temperature	0 to +55°C
Vibration resistance	Conforming to JIS-C-0911 10 to 57 Hz with single duplicate 0.075 mm. 57 to 150 Hz at constant acceleration 9.8 m/s ² (1 G) (2 hours each in X, Y, Z directions)
Shock resistance	Conforming to JIS-C-0912 147 m/s ² (15 G) (3 times each in X, Y, Z directions)
Withstand voltage	1000 VAC for one minute (between input/output terminal, power terminal and secondary circuit)
Insulation resistance power	500 VDC, more than 10 M-ohm (between input/output terminal, terminal and secondary circuit)
Insulation system	Photo-coupler
Protection structure	IEC standard IP67 (Dust-proof, splash-proof type)
Weight	Approx. 660 g
Accessory	One instruction manual

(2) Communication specifications


Item	Specifications
Data transfer rate	EIA RS485 or equivalent
Transfer rate	345.6 k bits/s, 172.8 k bits/s (automatically changes according to the data transfer speed of master station.
Transfer format	Asynchronous system
Coding method	NRZ (Non Return to Zero)
Frame check	Parity check and reverse-double verification
Synchronous mode	Asynchronous
Transfer mode	Time sharing cyclic digital system
Communication line	Parity line: Shielded twisted pair cable Cable total length : 1 km max. Recommended cable type: MRC-SB-5C by Nichigo Tsushin Wires
Connection with external lines	Plug connection (plug itself is not supplied) Recommended plug: Tajimi wireless electric For input (socket); TRC02-16P 7FA-ø11.2 For output (pins); TRC02-16P 7MA-ø11.2

A1

(3) Specifications of I/O

① ZW-84NC (24 VDC input module)

Item	Specifications
No. of slave station occupied bytes	1 bytes
No. of input point	8 points
Rated input voltage	24 VDC
Allowable input voltage	20.4 to 26.4 VDC
Rated input current	4.6 mA TYP. (at 24 VDC)
Input voltage level	ON level: 18.0 V or less, OFF level: 8.0 V or more
Input current level	ON level: 3 mA or less, OFF level: 1.5 mA or more
Input impedance	5.2 k ohm TYP.
Surge current	-
Response time (module alone)	OFF → ON: 1.0 ms or less ON → OFF: 1.5 ms or less
Common terminal	1 common per 8 points
Operation indication	Light LEDs at ON
External wire connection system	Round water-proof connector for sensor. One connector for one input. (Connectors for external connections are not supplied.) Specified connector: IEC standard M12, 4 cores, DC use, male, with gold plated terminals.




A1

② ZW-162MC (transistor output, 24 VDC input module)


Item		Specifications
No. of slave station occupied bytes		2 bytes (Output : Front 1 byte, Input : Back 1 byte)
Output specification	No. of output point	8 points
	Rated load voltage	24 VDC
	Allowable load voltage	20.4 to 26.4 VDC
	Rated max. output power	0.3 A/point, 1 A/common ※1
	Surge ON current	Output element capacity: 2 A (100 ms)
	Min. load current	—
	Leakage current (when OFF)	0.05 mA or less
	ON voltage	0.5 V or less (0.3 A)
	Response time (module alone)	OFF → ON: 1 ms or less ON → OFF: 1 ms or less (resistance load) ※2
	Surge killer	Zener diode
	Rated fuse	Built-in 1.25 A fuse (unable replacement) Meltdown detection function is provided (When melted down or lead power is turned off, the FUSE lamp lights) Note : This fuse protects against abnormal heating, and burning out the module. It is not for overcurrent protection of the output elements or load.
	Common terminal	1 common per 8 points (— common)
	Input specification	No. of input point
Rated input voltage		24 VDC
Allowable input voltage		20.4 to 26.4 VDC (includes ripple factor at 12/24 VDC)
Rated input current		4.6 mA TYP. (at 24 VDC)
Input voltage level		ON level: 18.0 V or less, OFF level: 8.0 V or up
Input current level		ON level: 3 mA or less, OFF level: 1.5 mA or up
Input impedance		5.2 k ohm (TYP.)
Surge current		—
Response time (Module alone)		OFF → ON: 1.0 ms or less (24 VDC) ON → OFF: 1.5 ms or less (24 VDC)
Common terminal	1 common line for 8 points (no polarity)	
External wire connection system	Round water-proof connector for sensor. One connector for one input. (Connectors for external connections are not supplied.) Specified connector: IEC standard M12, 4 cores, DC use, male, with gold plated terminals.	

Note 1: When you supply load power from the input/output connector, make sure that the total internal consumption current (110 mA), current for the 3-line external sensor, and load current are be less than 1 A.

Note 2: When you use an inductive load, the time delay from ON to OFF may be more than one second with a load value OFF.




[4] External dimension drawings (Common for ZM-84NC/ZW-162MC)



A1

Appendix 2. Check Flow



A2

Appendix 3. Address Allocation Table of an I/O Link Slave Module

I/O link relay ⁽⁸⁾	Used slave module
00	Status
01	
02	
03	
04	
05	
06	
07	
10	
11	
12	
13	
14	
15	
16	
17	
20	
21	
22	
23	
24	
25	
26	
27	
30	
31	
32	
33	
34	
35	
36	
37	

I/O link relay ⁽⁸⁾	Used slave module
40	
41	
42	
43	
44	
45	
46	
47	
50	
51	
52	
53	
54	
55	
56	
57	
60	
61	
62	
63	
64	
65	
66	
67	
70	
71	
72	
73	
74	
75	
76	
77	

SHARP

SHARP MANUFACTURING SYSTEMS CORPORATION