

SHARP

Graphing Calculator

EL-9650/9600c/9450/9400

Handbook Vol. 2

Programmes



EL-9650



EL-9450

Contents

1. Heron's Formula	1
2. Calculating Tension	2
3. Involute (Inverse Involute)	4
4. Calculating Illuminance and Luminous Intensity	6
5. Calculating Simple Harmonic Oscillation	8
6. Electric Power Consumed on an AC Circuit	10
7. Angle of Vector*	12
8. Linear Transformation*	14
9. Moving Average	16
10. Creating a Graph of Experimental Data	18
11. Ordinary Differential Equations	20
12. Analysing with One-way Layout Method	22
13. Calculating Parabolic Motion	25

*only for EL-9650/9600c

Read this first

This handbook was produced for practical application of the SHARP EL-9650/9600c and EL-9450/9400 Graphing Calculator. Both calculators include a highly convenient programming function, which enables automatic processing of both simple and complex calculations any number of times.

Note: Certain problems can not be solved with the EL-9450/9400 as indicated in contents.

1. Entering and Editing a Programme:

Programmes can be entered and edited either by pressing the calculator keys or by downloading from a PC. To download programmes from a PC, you will need the CE-LK1P PC link software (sold separately).

A. Using calculator keys


- Creating a new programme:

1. Press **2nd F PRGM** to display the programme menu.
2. Press **C ENTER** to select the new programme menu. (See right)
3. Enter the programme title, then press **ENTER**.
4. Enter the programme.
5. Press **2nd F QUIT** to finish programming.



- Editing a programme:

1. Press **2nd F PRGM** to display the programme menu.
2. Press **B** and choose the number of the programme you wish to edit.
3. Press **2nd F QUIT** to finish editing. (See right)



B. Downloading from PC

- Creating a new programme:

1. Using the CE-LK1P, select the **Model Type** from the **Tools** menu and click on the same model as your calculator.
2. Select **New** from the **File** menu.
3. Enter a programme name in **Title**:
4. Enter a programme. (For details on entering a programme, refer to the operation manual.) (See right)



- Programmes can also be downloaded from Sharp's website at <http://sharp-world.com/products/calculator/education/program/index.html> instead of creating a new programme.

- Sending programmes from a PC:

1. Using the CE-LK1P, select the **Communication Port** from the **Link** menu and click on the port to be used.
2. Turn off the EL-9650/9600c/9450/9400 and connect it to the PC.
3. Turn on the EL-9650/9600c/9450/9400
4. Select **Send...** from the **Link** menu of the CE-LK1P (See right)
5. Specify the kind of drive, folder, and file, then select the file to be sent from the file list, and click on the **Select** button.
6. Click on the **OK** button.



Note : For further details refer to the manual.

2. Executing a programme:

1. Press **2nd F PRGM** to display the execute menu.
2. Press **A ENTER** and choose the number of the programme you wish to execute. (See right)
3. Follow the instructions.



3. Deleting a programme:

Press **2nd F OPTION C** and then choose **5** to select the programme to be deleted.



Note: Do not try to erase a programme by resetting all memories to the initial condition as programme data to be stored will also be deleted. Also, it is advised to use the CE-LK1P PC link software to back up any programmes not to be erased.



4. Using the keys:

Press **2nd F** to use secondary functions (in yellow).

To select "sin⁻¹": **2nd F sin** → Displayed as follows: **2nd F sin⁻¹**

Press **ALPHA** to use the alphabet keys (in blue).

To select A: **ALPHA sin** → Displayed as follows: **ALPHA A**

Press **2nd F A-LOCK** to continue input of blue letters.

To input ABC: **ALPHA A ALPHA B ALPHA C** or **2nd F A-LOCK A B C**
(To return to the normal function, press **ALPHA** again.)


5. Troubleshooting:

Following is a list of error codes and error messages.

When errors occur, refer to pages 12, 254, or 27 of the manual.

Error code	Error message	Error content
01	Syntax	Syntax error in equation or programme
02	Calculate	Execution of a division using 0, calculation beyond calculation range, etc.
03	Nesting	Reservation of 14 or more numerical values or 32 or more functions during execution.
04	Invalid	Matrix definition error
05	Dimension	Inconsistency in the dimension of matrix during arithmetic of a matrix or dimension of list for STAT calculation.
07	Invalid DIM	Size of list and matrix input for calculation exceeds calculation range.
08	Argument	Inconsistency in argument of the structured function
09	Data Type	Invalid data type used in calculation
11	No define	Undefined list or matrix
12	Domain	Argument definition outside of domain
13	Increment	Increment error
17	Stat Med	Med-Med law (statistic) error
20	No Argument	No argument entered
21	Not pair \int dx	Equation definition (\int and dx as a pair) for integral calculus does not follow syntax.
22	Not pair []	Not paired with specified "[]"
23	Not pair ()	Not paired with specified "()"
24	Not pair {}	Not paired with specified "{}"
32	No data	Data does not exist
33	Graph Type	Error in graph type setting
37	No title	No title entered
38	Too many obj	More than 30 objects selected
40	Lbl duplicate	Same label name is used more than once within a programme
41	Lbl undefined	Label is not defined for Goto or Gosub
42	Lbl over	More than 50 labels are used within a programme
43	Gosub stack	Nesting of more than 10 subroutine stacks
44	Line too long	One line of programme exceeds more than 160 characters
45	Can't return	Use of return command without jumping from subroutine
46	Strage full	Attempt to create a file exceeding 99 (delete unnecessary files)
47	Coord type	Invalid coordinate system for command
90	Memory over	Over memory capacity
99	System error	User memory space cannot be secured

6. Page Layout



Note: This handbook is only an example of how to use programming function of the EL-9650/9600c. The layout may vary with each screen.


Heron's Formula

Use Heron's formula to find the area of a triangle when the sides (A,B,C) of the triangle are known.


Calculation

$$S = \sqrt{D(D - A)(D - B)(D - C)}$$

$$D = \frac{(A + B + C)}{2}$$



FLOWCHART



PROGRAMME LIST (REAL MODE)

Title : HERON

```

Print "Input LENGTH
Input A
Input B
Input C
(A+B+C)/2⇒D
√(D(D-A)(D-B)(D-C))⇒S
Print "S =
Print S
End
  
```

PARAMETERS

Name of parameter	Content	Name of parameter	Content
A	value of side A	D	value of D
B	value of side B	S	area
C	value of side C		

Exercise

Find the area of a triangle when sides A, B and C are 20, 35 and 40cm respectively.

Step

Key Operation

Display

(When using EL-9650/9600c)

- 1** Specify the programme mode.
Select the title HERON.

2nd F **PRGM** **A***

HERON
INPUT LENGTH
A=?

- 2** Enter the values A, B and C.

2 **0** **ENTER** **3** **5**
ENTER **4** **0** **ENTER**

A=	20
B=	35
C=	40
S=	349.944192

(Display of area)

- 3** The area is approximately 350cm².

Calculating Tension

Use the law of sines to find the tension when a pole of weight W is suspended with two strings, and the strings are balanced with the angles from the vertical line A and B.


Calculation

$$\frac{T}{\sin B} = \frac{S}{\sin A} = \frac{W}{\sin (A+B)}$$


$$\therefore T = W \frac{\sin B}{\sin (A+B)}$$

$$\therefore S = W \frac{\sin A}{\sin (A+B)}$$

T, S : tension W : weight
A, B : angles (6 sexagesimal numbers)



FLOWCHART



PROGRAMME LIST (REAL MODE)

Title : TENSION
Print "Input ANGLE
Input A
Input B
Print "Input WEIGHT
Input W
sin (A+B)⇒C
W* sin B/C⇒T
W* sin A/C⇒S
Print "TENSION
Print "T=
Print T
Print "S=
Print S
End

PARAMETERS

Name of parameter	Content	Name of parameter	Content
A	angle A	S	tension S
B	angle B	T	tension T
C	sin(A+B)	W	weight

Exercise

Calculate the tension assuming weight=40kg, angle A= $30^{\circ} 15' 20''$, and angle B= $27^{\circ} 45' 40''$. Enter the angles with sexagesimal numbers.

Set up condition: decimal point digit number in TAB 3 Mode, decimal point in Fix Mode, and angle unit in Deg Mode.

2nd F SET UP C_* 2_* D_* 3_* B_* 1_* CL

Step**Key Operation****Display**

(When using EL-9650/9600c)

- 1** Specify the programme mode.
Select the title TENSION.

2nd F PRGM A_*

TENSION
Input ANGLE
A=?

- 2** Enter the values of angles A and B.

3 0 . 1 5 2 0

ENTER

2 7 . 4 5 4 0

ENTER

Input ANGLE
A=
30.1520
B=
27.4540
Input WEIGHT
W=?

- 3** Enter the value of weight.

4 0 ENTER

Input WEIGHT
W=
40
TENSION
T=
21.840
S=
23.795

- 4** Tension T is 21.840kg and S is 23.795kg.

Involute (Inverse Involute)

Use the involute function for calculating gears etc. to find the angle of obliquity from the initial value and involute value.

Conversely, calculate the involute value from the angle of obliquity.

Calculation

Involute function : $\text{inv } \theta = \tan \theta - \theta [\text{rad}]$

Use Newton's method to find the inverse involute:


$$\theta_{i+1} = \theta_i - \frac{f(\theta)}{f'(\theta)} = \theta_i - \frac{\tan \theta_i - \theta_i - a}{\tan^2 \theta_i}$$

$$f(\theta) = a - \text{inv } \theta$$


SP : involute curve

S : involute starting point

θ : angle of obliquity of point P



FLOWCHART



PROGRAMME LIST (REAL MODE)

```

Title : INVOLUTE
Label START
ClrT
Print "SELECT 1/2"
Input S
If S=1 Goto ANGLE
If S=2 Goto INVO
Goto START
Label ANGLE
Print "Input BEGIN"
Input B
B → Z
Print "Input INVO"
Input I
I → J
Label CALPRESS
tan Z → T
π*Z/180.0 → R
(T-R-J)/T² → D
180.0*(R-D)/π → Z
If int (10^8 * D) ≠ 0 Goto CALPRESS
Z → A
Print "ANGLE"
Print A
End
Label INVO
Print "Input ANGLE"
Input A
A → θ
tanθ - π*θ/180 → I
Print "INVOLUTE"
Print I
End
  
```

PARAMETERS

Name of parameter	Content	Name of parameter	Content
D, R, T, J	working variable for calculating	θ	angle of obliquity
S	selecting calculation type (S=1: involute calculation) (S=2: inverse involute calculation)	I	involute value
Z	initial value, angle of obliquity	A	input and output of angle
		B	input of initial value

Exercise

- (1) Find the angle of obliquity when the involute value is 0.0050912 and the initial value is 10.
 (2) Find the involute value when the angle of obliquity is 14.1.

Set up condition: angle unit in Deg Mode and decimal point in Float Pt Mode.

2nd F SET UP B* 1* C* 1* CL

Step**Key Operation****Display**

(When using EL-9650/9600c)

- 1** Specify the programme mode.
 Select the title INVOLUTE.

2nd F PRGM A*

SELECT 1/2
S=?

- 2** Select involute calculation.

1 ENTER

SELECT 1/2
S=?
1
Input BEGIN
B=?

- 3** Enter the initial value and the involute value.

1 0 ENTER

**0 . 0 0 5 0 9 1 2
ENTER**

INPUT BEGIN
B= 10
INPUT INVO
I= 0.0050912
ANGLE 14.09998733

(Display of angle of obliquity)

- 4** Select inverse involute calculation.

ENTER

2 ENTER

SELECT 1/2
S=?
2
Input ANGLE
A=?

- 5** Enter the value of the angle of obliquity.

1 4 . 1

ENTER

(Display of involute value)

SELECT 1/2
S=?
2
Input ANGLE
A= 14.1
INVOLUTE .005091213

Calculating Illuminance and Luminous Intensity


Enter the luminous intensity of the luminous source, the distance, and the angle between the perpendicular line and light ray, to find the illuminance of the illuminated side.

Conversely, find the luminous intensity of the source from the illuminance of the illuminated side.


Calculation

$$i = \frac{l \cdot \cos \theta}{r^2} \quad l = \frac{r^2 \cdot i}{\cos \theta}$$

i : luminous intensity [candela] i : illuminance [lux]
 r : distance [m] θ : angle [$^\circ$]



FLOWCHART



PROGRAMME LIST (REAL MODE)

Title : CAND LUX

```

Label START
ClrT
Print "CANDELA=1 LUX=2
Print "SELECT 1/2
Input S
If S=1 Goto CANDELA
If S=2 Goto LUX
Goto START
Label CANDELA
Gosub DISTANCE
Print "Input LUX
Input L
L → I
R^2*I/cos θ → C
Print "CANDELA
Print C
End
Label LUX
Gosub DISTANCE
Print "Input CANDELA
Input C
C → K
K*cos θ /R^2 → L
Print "LUX
Print L
End
Label DISTANCE
Print "Input DISTANCE
Input D
D → R
Print "Input ANGLE
Input A
A → θ
Return
  
```

PARAMETERS

Name of parameter	Content	Name of parameter	Content
I	illuminance of illuminated side	θ	angle
K	luminous intensity of luminous source	A	input of angle
R	distance	L	input and calculating luminous intensity
S	selecting calculation type (S=1: calculation of luminous intensity) (S=2: calculation of illuminance)	D	input of distance
		C	input and calculating illuminance

Exercise

- (1) Find the luminous intensity of the luminous source of distance 10m, angle 60° and illuminance 20 lux.
 (2) Find the illuminance of the illuminated side of distance 10m, angle 60° and luminous intensity 4000 candela.

Set up condition: angle unit in Deg Mode and decimal point in Float Pt Mode.

2nd F SET UP B* 1* C* 1* CL

Step**Key Operation****Display**

(When using EL-9650/9600c)

- 1** Specify the programme mode.
 Select the title CAND LUX.

2nd F PRGM A*

CANDELA=1 LUX=2
SELECT 1/2
S=?

- 2** Select calculation of luminous intensity.

1 ENTER

CANDELA=1 LUX=2
SELECT 1/2
S=?
1
Input DISTANCE
D=?

- 3** Enter the values of distance, angle, and illuminance.

1 0 ENTER 6 0 ENTER

2 0 ENTER

(Display of luminous intensity)

SELECT 1/2
S=?
1
Input DISTANCE
D=?
10
Input ANGLE
A=?
60
Input LUX
L=?
20
CANDELA
4000

- 4** Select calculation of illuminance.
 Enter the values of distance, angle, and luminous intensity.

ENTER 2 ENTER

1 0 ENTER

6 0 ENTER

4 0 0 0 ENTER

(Display of illuminance)

Input ANGLE
A=?
60
Input CANDELA
C=?
4000
LUX
20

Calculating Simple Harmonic Oscillation

Enter period, amplitude and time to calculate displacement at specified time, acceleration, angular velocity, and velocity. Also, display the changes during the entered time period on a graph.

Calculation

$$\text{angular velocity} : \omega = \frac{2\pi}{T}$$

$$\text{acceleration} : a = -\omega^2 \times x$$

A : amplitude


t : time [sec]

T : period [sec]


ω : angular velocity [rad/sec]

$$\text{displacement} : x = A \times \sin(\omega t)$$

$$\text{velocity} : v = A \times \omega \times \cos(\omega t)$$



FLOWCHART



PROGRAMME LIST (REAL MODE)

Title : OSCILLAT

```

Print "Input PERIOD
Input P
P⇒F
Print "Input AMPLITUDE
Input A
A⇒D
Label CALC
Print "Input TIME
Input T
T⇒E
2*π/F⇒W
D*sin (W*E)⇒H
-(W^2)*H⇒B
D*W*cos (W*E)⇒V
Print "ANGULAR VELOCITY
Print W
Print "MAGNITUDE
Print H
Print "ACCELERATION
Print B
Print "VELOCITY
Print V
Wait
E/10⇒X scl
D/5⇒Y scl
0⇒Xmin:E⇒Xmax
-D⇒Ymin:D⇒Ymax
Draw D*sin (W*X)
Wait
ClrT
ClrG
Goto CALC

```

PARAMETERS

Name of parameter	Content	Name of parameter	Content
B	acceleration	A	input of amplitude
E	time	P	input of period
V	velocity	T	input of time
W	angle of velocity (ω)	D	amplitude
H	displacement	F	period
Xscl	x-axis scale	X	time increase
Yscl	y-axis scale		

Exercise

Calculate angular velocity, etc., using period π , amplitude 1 and time 3 seconds and display the changes on a graph.

Set up condition: angle unit in Rad Mode and decimal point in Float Pt Mode.

2nd F SET UP B * 2 * C * 1 * CL

1

Specify the programme mode.
Select the title OSCILLAT.

2nd F PRGM A *

Display
(When using EL-9650/9600c)

OSCILLAT
Input PERIOD
 $P=?$

2

Enter the values of period,
amplitude, and time.

2nd F π ENTER 1 ENTER 3

OSCILLAT
Input PERIOD
 $P=$
 π
Input AMPLITUDE
 $A=$
1
Input TIME
 $T=$
3

3

(Display of angular velocity)
(Display of displacement)
(Display of acceleration)
(Display of velocity)


ENTER

ANGULAR VELOCITY 2
MAGNITUDE 2.79415498
ACCELERATION 1.117661993
VELOCITY 1.920340573

4

(Display of graph of simple
harmonic oscillation)

ENTER

**5**

ENTER

Input TIME
 $T=?$

Electric Power Consumed on an AC Circuit

Enter the voltage effective value, frequency and resistance value to find the power value of the circuit with resistance R. Draw a graph of the changes in power over a period of time.

Calculation

P : power consumption I : effective value of current

V : effective value of voltage

$$I_0 = N \cdot \sin \omega \cdot t \quad V_0 = M \cdot \sin \omega \cdot t \quad P_0 = I_0 \cdot V_0$$


P_0 : change in amount of power with time

I_0 : change in amount of current with time


V_0 : change in amount of voltage with time

N: maximum value of current M: maximum value of voltage

ω : angular velocity ($2\pi S$) t : time S : frequency



FLOWCHART



PROGRAMME LIST(REAL MODE)

Title : AC POWER

Print "Input RESISTANCE

Input R

Print "Input VOLTAGE

Input V

Print "Input FREQUENCY

Input F

$R \Rightarrow T$

$V \Rightarrow D$

$F \Rightarrow S$

$2\pi S \Rightarrow W$

$D \sqrt{2} \Rightarrow M$

$M/T \Rightarrow N$

$N/\sqrt{2} \Rightarrow I$

$D \cdot I \Rightarrow Z$

$1/S \Rightarrow Xmax$

$Xmax/10 \Rightarrow Xscl$

$N \cdot M \Rightarrow Ymax$

$Ymax/10 \Rightarrow Yscl$

Print "WATT=

Print Z

Wait

$0 \Rightarrow Xmin$

$0 \Rightarrow Ymin$

Draw $N \cdot M \cdot (\sin(W \cdot X))^2$

End

PARAMETERS

Name of parameter	Content	Name of parameter	Content
S	frequency	Xscl	scale of x-axis
I	effective value of current	Ymax	maximum value of y-axis
T	resistance value	Yscl	scale of y-axis
D	effective value of voltage	V	input of voltage
W	angular velocity	R	input of resistance value
N	maximum value of current	F	input of frequency
M	maximum value of voltage	Z	value of power
Xmax	maximum value of x-axis		

Exercise

Find the power value of an AC circuit with resistance value 150Ω , voltage effective value 100V and frequency 50Hz and display on a graph the changes in power over a period of time.

Set up condition: angle unit in Rad Mode and decimal point in Float Pt Mode.

2nd F SET UP [B]* [2]* [C]* [1]* [CL]

Step**Key Operation****Display**

(When using EL-9650/9600c)

- 1** Specify the programme mode.
Select the title AC POWER.

2nd F PRGM [A]*

AC POWER
Input RESISTATCE
R=?

- 2** Enter the resistance value, voltage effective value, and frequency.

1 5 0 ENTER
1 0 0 ENTER
5 0 ENTER


Input RESISTATCE
R=
150
Input VOLTAGE
V=
100
Input FREQUENCY
F=
50
WATT= 66.66666667

(Display of value power)

- 3**

ENTER

(Display of graph)



Angle of Vector

Use the matrix operation feature to find the angle θ which forms the standard vector and vector. The angle can be calculated at one time against the multiple vectors.


Calculation

Calculating vector inner product $\vec{a} \cdot \vec{b} = |\vec{a}| |\vec{b}| \cos \theta$

Use the above expression to derive the following expression

$$\theta = \cos^{-1} \frac{\vec{a} \cdot \vec{b}}{|\vec{a}| |\vec{b}|}$$

FLOWCHART



PROGRAMME LIST (MATRIX MODE)

```

Title : VECTOR
0⇒I
0⇒K
Print " Input NUMBER
Input N
N⇒M
{M,2}⇒dim (mat A)
{2,1} ⇒ dim (mat B)
{M,1}⇒dim (mat C)
Label DATA
K + 1⇒K
Print " Input VECTOR
Print K
Input X
X⇒mat A(K,1)
Input Y
Y⇒mat A(K,2)
If K<M Goto DATA
Print "Input FUNDAMENTAL VECTOR
Input X
X⇒mat B(1,1)
Input Y
Y⇒mat B(2,1)
√(mat B(1,1)^2+mat B(2,1)^2)⇒B
mat A*mat B⇒mat C
Label CALC
I + 1⇒I
If I>M Goto END
√(mat A(I,1)^2+mat A(I,2)^2)⇒A
cos⁻¹ (mat C(I,1) / (A*B))⇒θ
Print "ANGLE OF VECTOR
Print I
Print "θ=
Print θ
Wait
Goto CALC
Label END
End
  
```

PARAMETERS

Name of parameter	Content	Name of parameter	Content
A	vector scalar quantity	θ	vector angle
B	standard vector scalar quantity	K	display
I	calculating counter	N	input of number of vectors
K	input counter	mat A	vector components
M	number of vectors	mat B	standard vector components
X	input of x component	mat C	vector inner product
Y	input of y component		

Exercise

Calculate the angle formed by the following 3 vectors and standard vector (2,3).

vector 1 (5, 8)

vector 2 (7, 4)

vector 3 (9, 2)

Set up condition: angle unit in Deg mode, and decimal point in Float Pt mode.

2nd F SET UP B * 1 * C * 1 * CL

Step	Key Operation	Display
1	Specify the programme mode. Select the title VECTOR.	2nd F PRGM A*
2	Enter the number of vectors.	3 ENTER
3	Enter the values of vector 1.	5 ENTER 8 ENTER
4	Enter the values of vectors 2 and 3.	7 ENTER 4 ENTER 9 ENTER 2 ENTER
5	Enter the value of standard vector. (Display of angle of vector 1)	2 ENTER 3 ENTER X= 2 Y= 3 ANGLE OF VECTOR 1 θ= 1.684684318
6	(Display of angle of vector 2) (Display of angle of vector 3)	ENTER X= 2 Y= 3 ANGLE OF VECTOR 2 θ= 26.56505118 X= 2 Y= 3 ANGLE OF VECTOR 3 θ= 43.78112476

Linear Transformation

Use the matrix to find four types of the linear transformation of x-axis symmetric transformation, y-axis symmetric transformation, similar transformation and revolution around the origin.

Calculation

- Symmetric transformation to x-axis (Case 1)

$$\begin{pmatrix} X' \\ Y' \end{pmatrix} = \begin{pmatrix} 1 & 0 \\ 0 & -1 \end{pmatrix} \begin{pmatrix} X \\ Y \end{pmatrix}$$

- Symmetric transformation to y-axis (Case 2)

$$\begin{pmatrix} X' \\ Y' \end{pmatrix} = \begin{pmatrix} -1 & 0 \\ 0 & 1 \end{pmatrix} \begin{pmatrix} X \\ Y \end{pmatrix}$$


- Similar transformation with ratio of similitude K around origin (Case 3)

$$\begin{pmatrix} X' \\ Y' \end{pmatrix} = \begin{pmatrix} K & 0 \\ 0 & K \end{pmatrix} \begin{pmatrix} X \\ Y \end{pmatrix}$$

- Transformation revolving around only angle B at the origin (Case 4)

$$\begin{pmatrix} X' \\ Y' \end{pmatrix} = \begin{pmatrix} \cos B & -\sin B \\ \sin B & \cos B \end{pmatrix} \begin{pmatrix} X \\ Y \end{pmatrix}$$

FLOWCHART



PARAMETERS





Name of parameter	Content	Name of parameter	Content
B	angle	Y	y-coordinate
K	ratio of similitude	A	input of angle
S	selecting type (S=1: case 1, S=2: case 2, S=3: case 3, S=4: case 4)	R	input of ratio of similitude
	mat A	mat H	coordinate after transformation
	mat D		transformation data
X	x-coordinate		x,y-coordinate

Exercise

1. Transform symmetrically the point (3, 5) to the x-axis.
2. Rotate the point (2, 6) at 45° around the origin.

Set up condition: angle unit in Deg Mode and decimal point in Float Pt Mode.

2nd F SET UP B * 1 * C * 1 * CL

Step	Key Operation	Display
1	Specify the programme mode. Select the title LINE TRNS.	2nd F PRGM A*
2	Enter the values of the point.	3 ENTER 5 ENTER 
3	Select symmetric transformation to x-axis (case 1).	1 ENTER 
4	Select transformation revolving around only angle B at the origin (case 4).	ENTER 2 ENTER 6 ENTER 4 ENTER 
5	Enter the angle value.	4 5 ENTER 

Moving Average

Plot a moving average graph which helps to understand how the results change over a specified period. The progress of sales and amounts of consumption and production can also be seen.


Calculation

$$H_i = \frac{X_{i-(M-1)/2} + \dots + X_i + \dots + X_{i+(M-1)/2}}{M}$$

$$(I = 1 + \frac{M-1}{2}, 2 + \frac{M-1}{2}, \dots, n + \frac{M-1}{2})$$

H_i : moving average
 M : number of divisions
 X_i : data
 n : number of data

FLOWCHART



MAIN
 Enter unit for calculating average.
 Returns to entry of no. of divisions if the number of divisions more than no. of data.
 Range for graph set.
 I = 0, K = int (M/2)
 First calculation. Jumps to subroutine.
 Jumps to subroutine.
 Number of calculation times of moving sum judged.
 Repeated until calculation of no. of divisions performed.

LOOP1
 X = K, Y = H
 Jumps to subroutine.
 Jumps to subroutine.
 Jumps to subroutine.
 Jumps to subroutine.
 Judgment of end.

LOOP2
 Subroutine Setting of counter
 I = I + 1, J = I, S = 0
 Return
 Subroutine Calculation of moving sum
 Calculation of moving sum
 Return
 Subroutine Calculation of average
 Calculation of moving average
 Return

PROGRAMME LIST (STAT MODE)

Title : MVIN AVG
 Label MAIN
 Print "Input DIVISION"
 Input D
 $D \Rightarrow M$
 1_Stats L1
 If $M \geq n$ Goto MAIN
 Rem RANGE
 $(x_{max}-x_{min})/10 \Rightarrow Y_{sc}$
 $0 \Rightarrow X_{min}$
 $n \Rightarrow X_{max}$
 $1 \Rightarrow X_{sc}$
 $x_{min} \Rightarrow Y_{min}$
 $x_{max} \Rightarrow Y_{max}$
 $0 \Rightarrow I$
 $\text{int}(M/2) \Rightarrow K$
 Gosub COUNT
 Label LOOP1
 Gosub MOVINGSUM
 If $M \geq J$ Goto LOOP1
 Gosub AVERAGE
 Label LOOP2
 Label COUNT
 $K \Rightarrow X$
 $H \Rightarrow Y$
 Gosub COUNT
 Label LOOP3
 Gosub MOVINGSUM
 If $(I+M) > J$ Goto LOOP3
 Gosub AVERAGE
 Line (X, Y, K, H)
 If $K \neq (\text{int}(M/2))$ Goto LOOP2
 Wait
 End
 Label COUNT
 $I+1 \Rightarrow I$
 $I \Rightarrow J$
 $0 \Rightarrow S$
 Return
 Label MOVINGSUM
 $S+L1(J) \Rightarrow S$
 $J+1 \Rightarrow J$
 Return
 Label AVERAGE
 $S/M \Rightarrow H$
 $K+1 \Rightarrow K$
 Return

Parameters

name of parameter	content	name of parameter	content
H	moving average	S	moving sum
I	counter	X	starting point (x)
J	counter	Y	starting point (y)
K	counter	Yscl	scale of y-axis
M	number of divisions	B	input of number of divisions

Exercise

Find the moving average every three months (number of divisions: 3) from the following table of monthly sales.

Month	Jan.	Feb.	Mar.	Apr.	May.	Jun.	Jul.	Aug.
Sales[\$]	300	326	323	344	300	401	398	450

On the graph, Xmax = 8, Ymin = 300, and Ymax = 450.

Set up condition: decimal point in Float Pt Mode.

2nd F SET UP C * 1 * CL

1

Enter statistical data into L1.

STAT A * ENTER

No 1: L1 2: L2 3: L3

No	1: L1	2: L2	3: L3
1	300		
2	326		
3	323		
4	344		
5	300		
6	401		
7	398		
8	450		
9			

Step**Key Operation****Display**

(When using EL-9650/9600c)

3 0 0 ENTER 3 2 6
ENTER 3 2 3 ENTER
3 4 4 ENTER 3 0 0
ENTER 4 0 1 ENTER
3 9 8 ENTER 4 5 0
ENTER

No	1: L1	2: L2	3: L3
1	300		
2	326		
3	323		
4	344		
5	300		
6	401		
7	398		
8	450		
9			

2

Specify the programme mode.
Select the title MVIN AVG.

2nd F PRGM A *

**3**

Enter the number of divisions(3). 3 ENTER




Creating a Graph of Experimental Data

Graph the results of an experiment and examine the trends.

(Example: examined data relating to water vapour pressure and temperature.)

FLOWCHART



PROGRAMME LIST(STAT MODE)

```

Title : XY GRAPH
ClrG
Rem DRAWING SD
2 .Stats L1,L2
Rem RANGE
xmin⇒Xmin
xmax ⇒ Xmax
ymin ⇒ Ymin
ymax ⇒ Ymax
(Xmax-Xmin) / 10 ⇒ Xscl
(Ymax-Ymin) / 10 ⇒ Yscl
Rem BROKEN LINE
0 ⇒ I
Label DRAWLOOP
I+1 ⇒ I
L1(I) ⇒ X
L2(I) ⇒ Y
L1(I+1) ⇒ Z
L2(I+1) ⇒ W
Line(X,Y,Z,W)
If (I+1) < n Goto DRAWLOOP
Wait
End
  
```

PARAMETERS

Name of parameter	Content	Name of parameter	Content
I	counter	Y	y of line starting point
X	x of line starting point	W	y of line finishing point
Z	x of line finishing point		

*n = number of statistical data

Exercise

The following table shows examined water vapour pressure. Draw a graph of this data.

Temperature [°C]	0	10	20	30	40	50	60	70	80	90	100
Pressure [mmHg]	4.581	9.205	17.532	31.826	55.339	92.558	149.47	223.79	355.29	525.90	760.00

Set up condition: decimal point in Float Pt Mode.

2nd F **SET UP** **C*** **1*** **CL**

Step**Key Operation****Display**

(When using EL-9650/9600c)

- 1** Enter statistical data into L1 and L2.

STAT **A*** **ENTER**

No	1: L1	2: L2	3: L3
1	4.581		
2	9.205		
3	17.532		
4	31.826		
5	55.339		
6	92.558		
			760.00

- 2**

0 **ENTER** **1** **0** ...
1 **0** **0** **ENTER**

(Other numbers not shown)

No	1: L1	2: L2	3: L3
1	0	4.581	
2	10	9.205	
3	20	17.532	
4	30	31.826	
5	40	55.339	
6	50	92.558	
			760.00

- 3**

4 **.** **5** **8** **1** **ENTER**
... **7** **6** **0** **ENTER**


No	1: L1	2: L2	3: L3
7	60	149.47	
8	70	223.79	
9	80	355.29	
10	90	525.9	
11	100	760	
12			

- 4**

Specify the programme mode.
Select the title XY GRAPH.

2nd F **PRGM** **A***

(Drawing of graph)




Ordinary Differential Equations

Enter the initial conditions (X, Y) with the step H and interval T. Use Runge Kutta Gill method to solve the ordinary differential equation of first order.


Calculation

Use the following four steps of Runge Kutta Gill method to find the equation X_{n+1} and Y_{n+1} from X_n and Y_n . Input $Q_0 = 0$ at the starting point X_0 .

1. $K_0 = Hf(X_n, Y_n)$, $R_1 = (1/2)(K_0 - 2Q_0)$, $Y^{(1)} = Y_n + R_1$
2. $Q_1 = Q_0 + 3R_1 - (1/2)K_0$
 $K_1 = Hf(X_n + H/2, Y^{(1)})$, $R_2 = (1 - \sqrt{1/2})(K_1 - Q_1)$, $Y^{(2)} = Y^{(1)} + R_2$
3. $Q_2 = Q_1 + 3R_2 - (1 - \sqrt{1/2})K_1$
 $K_2 = Hf(X_n + H/2, Y^{(2)})$, $R_3 = (1 + \sqrt{1/2})(K_2 - Q_2)$, $Y^{(3)} = Y^{(2)} + R_3$
4. $Q_3 = Q_2 + 3R_3 - (1 + \sqrt{1/2})K_2$
 $K_3 = Hf(X_{n+1}, Y^{(3)})$, $R_4 = (1/6)(K_3 - 2Q_3)$, $Y_{n+1} = Y^{(3)} + R_4$
 $Q_4 = Q_3 + 3R_4 - (1/2)K_3$



FLOWCHART



PROGRAMME LIST (REAL MODE)

Title : RUNGE

```

Rem INITIAL    I+H/2⇒I      Goto MAIN
Print " Input X0 Rem 2
Input X          Gosub FORMULA Label NEXT
Print " Input Y0 H*F⇒K
Input Y          B*(K-Q)⇒ R
                  X⇒I           J+R⇒J
                  Y⇒J           Q+3*R-B*K⇒Q
                  Print "XN=      ClrT
                  Rem 3
Input H          Gosub FORMULA Print M
Print " Input T  H*F⇒K      Print "YN=
Input T          A*(K-Q)⇒ R Print N
                  1+√(2^1)⇒A J+R⇒J
                  1-√(2^1)⇒B Q+3*R-A*K⇒Q Wait
                  I+T⇒Z     I+H/2⇒I
                  O⇒Q      Rem 4
                  Rem 4
Label MAIN      Gosub FORMULA Goto MAIN
                  H*F⇒K
Rem 1           (K - 2*Q) /6⇒R Label SUB2
Gosub FORMULA  J+R⇒J
                  H*F⇒K
                  (K-2*Q) /2⇒R If Z≤I Goto NEXT
                  J+R⇒J
                  Q+3*R-K/2⇒Q I⇒S
                  P⇒N
                  Goto SUB1 Label FORMULA
                  -I*J⇒F
                  Return
  
```

PARAMETERS

Name of parameter	Content	Name of parameter	Content
A	value of $1 + \sqrt{1/2}$	S	value of X_{n-1}
B	value of $1 - \sqrt{1/2}$	T	interval
F	$f(I, J)$	I	X_n
H	step	J	Y_n
K	calculating working area	Z	value of increase of X
O	value of Y_{n-1}	X	input of X_0
P	increase of J	Y	input of Y_0
Q	value of Q_n	M	indicates X_n
R	value of R_n	N	indicates Y_n

Exercise

Initial settings: $Y = 10$ when $X = 0$. Find J when $H = 0.01$, $T = 0.03$ and $I = 0.03, 0.06\cdots$.
 (The built-in differential equation is $F = -I * J$.)

Set up condition: angle unit in Rad Mode and decimal point in
 Float Pt Mode.

2nd F SET UP B * 2 * C * 1 * CL

- 1** Specify the programme mode.
 Select the title RUNGE.

2nd F PRGM A *

Display
 (When using EL-9650/9600c)

RUNGE
 Input X_0
 $X=?$

- 2** Enter the values of X_0 , Y_0 ,
 H and T.

0 ENTER 1 0 ENTER

0 • 0 1 ENTER

0 • 0 3 ENTER

RUNGE
 Input X_0
 $X=$
 0
 Input Y_0
 $Y=$
 10
 Input H
 $H=$
 0.01
 Input T
 $T=$
 0.03

- 3**
 (Display of X_1)
 (Display of Y_1)

ENTER

XN= .03
YN= 9.995501012

- 4**
 (Display of X_2)
 (Display of Y_2)

ENTER

XN= .06
YN= 9.98201619

- 5**
 (Display of X_3)
 (Display of Y_3)

ENTER

XN= .09
YN= 9.959581902

Similar operation is performed
 hereafter.

Analysing with One-way Layout Method

Use the one-way layout method to verify whether there is a relation to the results achieved based on one condition. Analysis of variance is carried out with this method.


Calculation

Analysis of variance chart of one-way layout method

	Sum of squares (S)	Degree of freedom (θ)	Variance (V)	Variance ratio (F)
Factor	$S_A = [A] - [X]$	$\theta_A = A - 1$	$V_A = S_A / \theta_A$	$F_A = V_A / V_E$
Error	$S_E = [AS] - [A]$	$\theta_E = A(N - 1)$	$V_E = S_E / \theta_E$	
Total	$S_T = [AS] - [X]$	$\theta_T = AN - 1$		

$$\begin{aligned} [X] &= (\sum \sum X_{ij})^2 / AN \\ [A] &= \sum i (\sum j X_{ij})^2 / N \\ [AS] &= \sum i \sum j (X_{ij})^2 \\ A &: \text{number of levels} \\ N &: \text{repeated frequency} \\ X &: \text{number of data} \end{aligned}$$

FLOWCHART



PROGRAMME LIST(STAT MODE)

Title : VARIANCE

```

Rem INPUT
Print "Input LEVEL
Input L
L → A
Print "Input TIMES
Input T
T → N
0 → W
0 → B
0 → C
1 → S
Label LOOP2
N → dim(L1)
1 → K
Label LOOP1
ClrT
S → L
K → T
Print "SUM OF SQUARES
Print E
Print "ERROR SUM OF SQUARES
Print M
Wait
Print "TOTAL SUM OF SQUARES
Print P
Wait
Rem DEGREES OF FREEDOM
A-1 → Q
A*(N-1) → R
A*N-1 → D
Print "DEGREES OF FREEDOM
Print Q
Print "DEGREES OF FREEDOM _____
Print R
Wait
Print "SUM OF DEGREES OF FREEDOM
Print D
Wait
Rem VARIANCE
E/Q → V
M/R → U
Print "VARIANCE
Print V
Print "VARIANCE OF ERRORS
Print U
Wait
Rem VARIANCE RATIO
V/U → F
Print "VARIANCE RATIO
Print F
End

```

PARAMETERS

Name of parameter	Content	Name of parameter	Content
A	number of levels	V	variance factor
I	input of data	U	variance error
K	loop 1 counter	Y	$\Sigma i (\Sigma j x_{ij})^2 / n$
J	indicating Σx	Q	degree of freedom factor
N	repeated frequency	R	degree of freedom error
S	loop 2 counter	D	degree of freedom total
X	$(\Sigma \Sigma x_{ij})^2 / a/n$	T	input and indicating frequency
Z	$\Sigma i \Sigma j (x_{ij})^2$	L	input and indicating number of levels
F	variance ratio factor	W	total sum of squares of each level
E	sum of squares factor	B	total sum (all data)
M	sum of squares error	C	total sum of squares (all data)
P	sum of squares total		

Exercise

When a mouse is given a dosage of hormone, the relationship between dosage amount and increase of mouse weight is as shown in the following table. Find the analysis of variance. If the value of the variance ratio is larger than the value of the F-distribution table at the 5% level of significance, the relationship between the hormone amount and the increase of mouse weight is a causal relation.

		Increase mouse weight (grams/day)					
			10	20	30	40	50
Hormone (grams/mouse)	10	882	891	864	888	885	
	20	923	915	923	912	930	
	30	933	939	925	940	932	

The number of levels (number of columns in the table) is A = 3

The repeated frequency (number of rows in the table) is N = 5

Set up condition: decimal point in Float Pt Mode.

2nd F SET UP C * 1 * CL

Step

- 1** Specify the programme mode.
Select the title VARIANCE.

2nd F PRGM A *

Key Operation

(When using EL-9650/9600c)

VARIANCE
Input LEVEL
L=?

- 2** Enter the number of levels and the repeated frequency.

3 ENTER 5

VARIANCE
Input LEVEL
L=?
3
Input TIMES
T=?
5

3

ENTER

Input DATA LEVEL	1
TIME	1
I=?	

<u>Step</u>	<u>Key Operation</u>	<u>Display</u> (When using EL-9650/9600c)
4	Enter the statistical data in level 1. [ENTER] [8] [8] [2] [ENTER] [8] [9] [1] [ENTER] [8] [6] [4] [ENTER] [8] [8] [8] [ENTER] [8] [8] [5] [ENTER]	LEVEL TIME I= 885 Σx= 4410
	(Display of total of hormone 10 g)	
5	Enter the statistical data in level 2. [ENTER] [9] [2] [3] [ENTER] [9] [1] [5] [ENTER] [9] [2] [3] [ENTER] [9] [1] [2] [ENTER] [9] [3] [0] [ENTER]	LEVEL TIME I= 930 Σx= 4603
	(Display of total of hormone 20 g)	
6	Enter the statistical data in level 3. [ENTER] [9] [3] [3] [ENTER] [9] [3] [9] [ENTER] [9] [2] [5] [ENTER] [9] [4] [0] [ENTER] [9] [3] [2] [ENTER]	LEVEL TIME I= 932 Σx= 4669
	(Display of total of hormone 30 g)	
7	[ENTER]	I= 932 Σx= 4669 SUM OF SQUARES 7245.733334 ERROR SUM OF SQUARES 802
	(Display of sum of squares) (Display of error sum of squares)	
8	[ENTER]	Σx= 4669 SUM OF SQUARES 7245.733334 ERROR SUM OF SQUARES 802 TOTAL SUM OF SQUARES 8047.733334
	(Display of sum of squares)	
9	[ENTER]	TOTAL SUM OF SQUARES 8047.733334 DEGREES OF FREEDOM 12 DEGREES OF FREEDOM ABOUT ERRORS 12
	(Display of degrees of freedom) (Display of degrees of freedom about errors)	
10	[ENTER]	DEGREES OF FREEDOM 2 DEGREES OF FREEDOM ABOUT ERRORS 12 SUM OF DEGREES OF FREEDOM 14
	(Display of sum of degrees of freedom)	
11	[ENTER]	SUM OF DEGREES OF FREEDOM 12 VARIANCE 3622.866667 VARIANCE OF ERRORS 66.83333333
	(Display of variance) (Display of variance of errors)	
12	[ENTER]	VARIANCE 14 VARIANCE OF ERRORS 66.83333333 VARIANCE RATIO 54.2074813
	(Display of variance ratio)	

The F-distribution chart shows that the value of F of upper probability P = 5% is 3.89. Since f > 3.98 in this example, the relationship between the hormone amount and the increase of mouse weight is a causal relation with 5% level of significance.


Calculating Parabolic Motion

Display on a graph the altitude change and the horizontal distance over a period of time when an object is thrown at initial velocity V_0 and angle θ , and find the horizontal distance and altitude after t seconds. Specify the angle in Deg.


Calculation

$$X = V_0 \cdot \cos \theta \cdot T \quad Y = V_0 \cdot \sin \theta \cdot T - \frac{1}{2} g T^2$$

Initial velocity V_0 [m/s]
 Angle θ [$^\circ$]
 Gravitational acceleration $g = 9.8$ [m/s 2]
 Time T [s]



FLOWCHART



PROGRAMME LIST(REAL MODE)

```

Title : PARABOLA
Print "V0 (M/S),θ,T(S) 0⇒Xmin
Print "Input V0 0⇒Ymin
Input V B⇒Xmax
2*V*sin 45/9.8⇒A C⇒Ymax
V2/9.8⇒B 0⇒D
V2/19.6⇒C Label LOOP1
Print "HMAX= V*cos θ*D⇒X
Print C V*sin θ*D-(0.5*9.8*D2)⇒Y
Print "LMAX= Pnt0N(X,Y)
Print B D+(T/100)⇒D
Print "TMAX= If D≤T Goto LOOP1
Print A Wait
Label TX
Wait Label THETA
Label TX
Input θ Input Z
If θ ≤ 0 Goto THETA If Z≤0 Goto THETA
If θ > 90 Goto THETA If Z>T Goto THETA
V2*(sin θ)2/19.6⇒H V*cos θ*Z⇒X
V2*sin (2θ)/9.8⇒L V*sin θ*Z-(0.5*9.8*Z2)⇒Y
2*V*sin θ/9.8⇒T Print "X=
Print H Print X
Print "L= Print "Y=
Print L Print Y
Print "T= Wait
Print T C/10⇒Yscl
Print TX Line(0,Y,X,Y)
Wait B/10⇒Xscl Line(X,0,X,Y)
Goto TX Wait
0000
  
```

PARAMETERS

Name of parameter	Content	Name of parameter	Content
H	highest altitude	Xscl	scale of x-coordinate
L	horizontal distance	Z	input of time period
T	time	V	initial velocity (V_0)
X	distance (after time Z)	θ	angle (released angle)
Y	altitude (after time Z)	C	highest altitude when released at 90°
D	time elapsed	B	horizontal distance when released at 45°
Yscl	scale of y-coordinate	A	time period when released at 45°

Exercise

Find the horizontal distance and altitude three seconds after an object is thrown, when the initial velocity is 25m/sec and the angle is 52° .

Set up condition: angle unit in Deg mode, and decimal point in Float Pt mode.

2nd F SET UP B * 1 * C * 1 * CL

- 1** Specify the programme mode.
Select the title PARABOLA.

2nd F PRGM A *

Display
(When using EL-9650/9600c)

PARABOLA
 V_0 (M/S), θ , T(S)
Input V_0
 $V=?$

- 2** Enter the value of the initial velocity.

2 5 ENTER

V=
25
HMAX= 31.8877551
LMAX= 63.7755102
TMAX= 3.607687659

- 3** **ENTER**


HMAX= 31.8877551
LMAX= 63.7755102
TMAX= 3.607687659
 $\theta=?$

- 4** Enter the angle value.

5 2 ENTER

B=
52
H= 19.80105063
L= 61.88110499
T= 4.020463029

- 5** **ENTER**
(Display of graph of parabola)



- 6** **ENTER**

H= 19.80105063
L= 61.88110499
T= 4.020463029
Input TX
 $Z=?$

- 7** Enter the value of time period Z.


3 ENTER

4.020463029
Input TX
 $Z=$
 $Z=$ 3
X= 46.17461065
Y= 15.00080652

- 8** **ENTER**
(Altitude and distance after Z seconds are displayed on the parabola graph.)



Key pad for the SHARP EL-9650/9600c Calculator



1 Graphing keys

2 Power supply ON/OFF key

3 Alphabet specification key

4 Secondary function specification key

5 Display screen

6 Cursor movement keys


7 Clear/Quit key

8 Variable enter key

9 Calculation execute key

10 Communication port for peripheral devices

Key pad for the SHARP EL-9450/9400 Calculator



- ① Graphing keys
- ② Power supply ON/OFF key
- ③ Alphabet specification key
- ④ Secondary function specification key
- ⑤ Display screen
- ⑥ Cursor movement keys
- ⑦ Clear/Quit key
- ⑧ Variable enter key
- ⑨ Calculation execute key
- ⑩ Communication port for peripheral devices

SHARP

Use this form to send us your contribution

Dear Sir/Madam

We would like to take this opportunity to invite you to create a mathematical problem which can be solved with the SHARP EL-9650/9600c and 9450/9400 graphing calculator, including the necessary procedures and definitions as outlined in the form below.

For this purpose, we would be grateful if you could complete the form and return it to us by fax or mail, specifying whether you have created the problem for the EL-9650/9600c or the EL-9450/9400. If your contribution is chosen, your name will be included in the next edition of The EL-9650/9600c/9450/9400 Graphing Calculator Handbook or on our homepage. We regret that we are unable to return contributions. Also, please note that the problems you send us might be opened to the public at Sharp's home page.

We thank you for your cooperation in this project.

Name: (<input type="checkbox"/> Mr. <input type="checkbox"/> Ms.)		
School/College/Univ.:		
Address:		
Post Code:		Country:
Phone:	Fax:	
E-mail:		

* You are making this sheet for the (EL-9650/9600c, EL-9450/9400).

SUBJECT: Write either a title or about the subject matter.

.....

INTRODUCTION and CALCULATION:

Write a brief explanation of the subject, and the formula with definitions, including a diagram if relevant.

.....



PARAMETERS:

Define the parameters used in the programme.

PROGRAMME LIST:

List the procedure of data to be entered.

EXERCISE and SET UP CONDITION:

Include an example of a problem which can be solved with the formula. Write a step-by-step guide to solving the problem with an explanation. Detail any important conditions to be set up before solving the problem.

SHARP
SHARP CORPORATION Osaka, Japan
Fax:

SHARP Graphing Calculator



SHARP

SHARP CORPORATION OSAKA, JAPAN